

TRIGGER PIVOT PIN, SS

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Blackhawk®; New Model Single-Six®; Super Blackhawk®, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero®



Attributes

- Name: TRIGGER PIVOT PIN, SS
- Manufacturer: RUGER
- Product no.: 780012091
- Mfr. No.: KXR03401
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: TRIGGER PIVOT PIN Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för TRIGGER PIVOT PIN, SS RUGER TRIGGER PIVOT PIN, SS](#)

TRIGGER PIVOT PIN Safety Instruction Guide

Introduction

Thank you for choosing the TRIGGER PIVOT PIN, designed for use with various Ruger firearms, including the Bisley™ Large Frame, Bisley™ Small Frame, New Model Blackhawk®, New Model SingleSix®, Super Blackhawk®, and Vaquero®. This guide provides essential safety instructions and best practices to ensure safe and effective use of your product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always read and understand the product instructions before use.
- Ensure that the product is suitable for your specific firearm model.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the product for any signs of wear or damage before use.
- Use the product only for its intended purpose as specified.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before installing or replacing the trigger pivot pin.
- Use protective eyewear when handling or working with firearms.
- Avoid using excessive force during installation to prevent damage to the firearm.
- Do not modify the trigger pivot pin or the firearm in any way that is not recommended by the manufacturer.
- Be aware of your surroundings and ensure that you are in a safe environment when handling your firearm.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is completely unloaded.
- Gather necessary tools for installation, such as screwdrivers and pliers.

2. Installation Steps

- Carefully remove the existing trigger pivot pin from the firearm.
- Align the new TRIGGER PIVOT PIN with the designated hole in the trigger assembly.
- Gently push or tap the pin into place, ensuring it is secure but not overly tight.
- Doublecheck that the pin is correctly positioned and that the trigger functions properly.

3. PostInstallation Check

- Test the trigger to ensure it operates smoothly without any obstruction.
- Inspect the installation area for any loose parts or debris.

4. Usage Guidelines

- Always follow safe firearm handling practices.
- Regularly check the trigger pivot pin for security and functionality during routine maintenance.

Disposal Instructions

- Dispose of any old or damaged trigger pivot pins in accordance with local regulations.
- Do not dispose of the product in household waste. Check for designated disposal facilities or recycling programs in your area.

Contact Information for Further Support

For any questions or concerns regarding the TRIGGER PIVOT PIN, please refer to your retailer or manufacturer's website for contact details and support.

By following these safety instructions, you can ensure a safe and effective experience with your TRIGGER PIVOT PIN. Always prioritize safety when handling firearms and seek assistance if you are unsure about any procedures. Thank you for your attention to these important guidelines.

Säkerhetsinstruktioner för TRIGGER PIVOT PIN, SS RUGER TRIGGER PIVOT PIN, SS

Introduktion

Tack för att du valt TRIGGER PIVOT PIN, SS RUGER TRIGGER PIVOT PIN, SS. Denna produkt är avsedd för användning med olika Rugermodeller, inklusive Bisley™ Stor Ram, Bisley™ Liten Ram, Ny Modell Blackhawk®, Ny Modell SingleSix®, Super Blackhawk®, .44 Mag, Super Blackhawk® Hunter, .44 Mag och Vaquero®. För att säkerställa en säker och effektiv användning av produkten, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten i enlighet med tillverkarens anvisningar.
- Kontrollera produkten för skador innan användning. Använd inte om den är skadad.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Kontrollera regelbundet för uppdateringar om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddsglasögon och handskar vid installation och användning.
- Se till att vapnet är avstängt och oladdat innan du installerar eller byter ut pivot pin.
- Undvik att använda produkten i ogynnsamma miljöer, såsom fuktiga eller extremt kalla områden.
- Var medveten om att felaktig installation kan leda till allvarliga skador eller olyckor.

Instruktioner för installation och användning

1. Förberedelse:

- Kontrollera att du har allt nödvändigt verktyg för installationen.
- Läs igenom alla instruktioner innan du påbörjar installationen.

2. Installation:

- Ta bort det gamla pivot pin om det finns ett installerat.
- Placera den nya TRIGGER PIVOT PIN i det avsedda facket.
- Se till att pinnen sitter ordentligt på plats och är säkrad.

3. Användning:

- Kontrollera att pivot pin är korrekt installerad innan du använder vapnet.
- Utför en säkerhetskontroll av vapnet efter installationen.
- Använd vapnet endast i enlighet med gällande lagar och förordningar.

Avfallsanvisningar

- Kasta bort trasiga eller oanvändbara delar av produkten på ett miljövänligt sätt.
- Följ lokala riktlinjer för avfallshantering när du gör dig av med produkten.
- Undvik att slänga produkten i vanliga hushållsavfall om den innehåller skadliga material.

Kontaktinformation för vidare support

För frågor eller ytterligare information om säkerheten kring TRIGGER PIVOT PIN, SS RUGER TRIGGER PIVOT PIN, SS, vänligen kontakta en auktoriserad återförsäljare eller tillverkaren. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för snabbare service.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är vår prioritet.