

BASE PIN LATCH SPRING, SS

[Handgun Parts](#) > [Action Parts](#) > [Base Pin Parts](#) > [Base Pin Springs](#)

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Bearcat®; Serial # Above 93-00000, .22; New Model Blackhawk®; New Model Single-Six®; Super Blackhawk®, .44 Mag; Vaquero®



Attributes

- Name: [BASE PIN LATCH SPRING, SS](#)
- Manufacturer: [RUGER](#)
- Product no.: 780012103
- Mfr. No.:
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for BASE PIN LATCH SPRING, SS
- About Us

Safety Instruction Guide for BASE PIN LATCH SPRING, SS

Introduction

Thank you for choosing the BASE PIN LATCH SPRING, SS. This product is designed for use with various Ruger models, including Bisley™ Large Frame, Bisley™ Small Frame, New Model Bearcat®, New Model Blackhawk®, New Model SingleSix®, Super Blackhawk®, and Vaquero®. It is essential to follow these safety instructions to ensure safe and effective use of the product.

General Safety Guidelines

- Always read and understand the instructions before using the product.
- Ensure that the product is compatible with your firearm model.
- Inspect the product for any signs of damage before installation.
- Keep the product out of reach of children and unauthorized users.
- Report any unsafe products or accidents to the appropriate authorities.
- Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure the firearm is unloaded before installing or replacing the base pin latch spring.
- Use only the recommended tools for installation to prevent damage.
- Do not modify the product in any way, as this may compromise safety.
- Always wear safety glasses when working with firearms.
- Store the product in a dry and secure location when not in use.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a screwdriver and safety glasses.

2. Installation Steps:

- Remove the old base pin latch spring carefully.
- Inspect the area for any debris or damage.
- Insert the new BASE PIN LATCH SPRING, SS into the designated slot.
- Ensure it is seated properly and securely.
- Replace any components removed during installation.

3. Usage:

- Once installed, test the functionality of the base pin latch.
- Ensure it operates smoothly and securely holds the base pin in place.
- If any issues arise, consult a qualified gunsmith before use.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not throw the product in regular household waste.
- Contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any inquiries or concerns regarding the BASE PIN LATCH SPRING, SS, please consult the retailer or manufacturer from whom you purchased the product. They can provide additional support and information regarding safety and usage.

Thank you for your attention to these safety instructions. Your safety and the safety of others is our top priority.

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se