

EJECTOR BOLT STOP, SS

FITS: Mini-14® Ranch Rifle Serial # Prefix 187-188, .223; Mini-30®, 7.62 x 39



Attributes

- Name: EJECTOR BOLT STOP, SS
- Manufacturer: RUGER
- Product no.: 780014009
- Mfr. No.:
- Make: Ruger
- Model: Mini-14,Mini-30
- Delivery weight: 0.009kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [English: EJECTOR BOLT STOP, SS Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för EJECTOR BOLT STOP, SS RUGER EJECTOR BOLT STOP, SS](#)

EJECTOR BOLT STOP, SS Safety Instruction Guide

Introduction

Thank you for purchasing the Ejector Bolt Stop, SS. This product is designed for use with Ruger Mini14® Ranch Rifle (Serial # Prefix 187188, .223) and Mini30® (7.62 x 39). This guide provides essential safety instructions to ensure the safe installation and usage of the product. Please read this guide carefully before use.

General Safety Guidelines

- Ensure that the Ejector Bolt Stop is compatible with your firearm model before installation.
- Always handle firearms with care and follow standard safety practices.
- Store the product in a safe location, out of reach of children and unauthorized users.
- Regularly inspect the Ejector Bolt Stop for signs of wear or damage.
- In case of any malfunction or unusual behavior, cease use immediately and consult a qualified gunsmith.

Specific Safety Precautions for Use

- Use only with Ruger Mini14® and Mini30® rifles as specified.
- Do not modify the Ejector Bolt Stop in any way.
- Ensure the firearm is unloaded before installation or maintenance.
- Wear appropriate safety gear, such as eye protection, when handling firearms.
- Be aware of your surroundings and ensure a safe shooting environment when using the firearm.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, including a screwdriver.

2. Installation:

- Locate the existing bolt stop on your firearm.
- Remove the old bolt stop carefully, taking note of the installation method.
- Align the Ejector Bolt Stop, SS with the mounting area.
- Secure the Ejector Bolt Stop in place using the appropriate screws or fasteners.

3. PostInstallation Check:

- Verify that the Ejector Bolt Stop is firmly installed and does not move.
- Conduct a function test to ensure the firearm operates correctly with the new part.

4. Usage:

- Follow all standard operating procedures for your firearm.
- Regularly check the Ejector Bolt Stop for proper function during routine maintenance.

Disposal Instructions

- Dispose of the Ejector Bolt Stop according to local regulations regarding firearm components.
- Do not dispose of in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Ejector Bolt Stop, please consult a qualified firearms expert or your local Ruger dealer. Ensure that you have the product details at hand for efficient assistance.

By following these guidelines, you will ensure the safe and effective use of the Ejector Bolt Stop, SS. Thank you for prioritizing safety in your firearm practices.

Säkerhetsinstruktioner för EJECTOR BOLT STOP, SS RUGER EJECTOR BOLT STOP, SS

Introduktion

Tack för att du valt EJECTOR BOLT STOP, SS för din Ruger Mini14® eller Mini30®. Denna produkt är utformad för att säkerställa säker och effektiv användning av ditt vapen. Denna säkerhetsinstruktionsguide syftar till att ge dig viktig information för att använda produkten på ett säkert sätt och i enlighet med EU:s allmänna produktsäkerhetsförordning (GPSR).

Allmänna säkerhetsriktlinjer

- Kontrollera alltid att produkten är i gott skick innan användning.
- Använd produkten endast för avsett ändamål.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Följ alltid tillverkarens instruktioner för installation och användning.
- Rapportera eventuella osäkra produkter eller olyckor till myndigheterna.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder vid användning

- Använd alltid skyddsglasögon och hörselskydd när du hanterar eller använder vapen.
- Kontrollera att vapnet är avstängt och tomt innan installation av EJECTOR BOLT STOP.
- Undvik att rikta vapnet mot dig själv eller andra under installation och användning.
- Använd produkten endast med kompatibla modeller: Mini14® Ranch Rifle (serienummerprefix 187188, .223) och Mini30® (7.62 x 39).
- Kontrollera att alla delar är korrekt installerade innan användning.

Instruktioner för installation och användning

1. Förberedelse:

- Se till att vapnet är avstängt och tomt.
- Samla nödvändiga verktyg för installationen.

2. Installation:

- Ta bort den gamla ejector bolt stop om det finns en.
- Placera EJECTOR BOLT STOP, SS på rätt plats enligt tillverkarens specifikationer.
- Säkerställ att den är ordentligt fastsatt och att inga delar är lösa.

3. Användning:

- Efter installationen, kontrollera att produkten fungerar som avsett.
- Använd vapnet enligt tillverkarens instruktioner och säkerhetsriktlinjer.

4. Efter användning:

- Rengör och underhåll produkten regelbundet för att säkerställa långvarig prestanda.
- Förvara produkten på en säker plats, utom räckhåll för barn.

Avfallsinstruktioner

- Kassera produkten i enlighet med lokala miljöbestämmelser.
- Om produkten är skadad eller utgången, se till att den inte kan användas av obehöriga.

Kontaktinformation för vidare stöd

För ytterligare information eller frågor angående säkerhet, installation eller användning av EJECTOR BOLT STOP, SS, vänligen kontakta tillverkaren eller återförsäljaren där produkten köptes.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din EJECTOR BOLT STOP, SS. Tack för att du prioriterar säkerheten!