

## GRIP FRAME SCREW, A-FRONT, SS

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Blackhawk®; New Model Single-Six™; Old Army™, .45; Super Blackhawk®, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero™



### Attributes

- Name: GRIP FRAME SCREW, A-FRONT, SS
- Manufacturer: RUGER
- Product no.: 780022009
- Mfr. No.:
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

### Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [English: GRIP FRAME SCREW, AFRONT, SS Safety Instruction Guide](#)
- [Svenska: Säkerhetsinstruktioner för GRIP FRAME SCREW, AFRONT, SS](#)

# GRIP FRAME SCREW, AFRONT, SS Safety Instruction Guide

## Introduction

Thank you for choosing the GRIP FRAME SCREW, AFRONT, SS. This product is designed for use with specific firearm models, ensuring enhanced performance and reliability. It is essential to follow safety guidelines to ensure a safe and effective experience.

## General Safety Guidelines

- Always handle firearms with care and in accordance with local laws and regulations.
- Ensure the product is compatible with your firearm model before use.
- Regularly inspect the GRIP FRAME SCREW for signs of wear or damage.
- Store the product in a safe place, away from children and unauthorized users.
- If you notice any defects or issues, discontinue use immediately and consult a qualified professional.

## Specific Safety Precautions for Use

- Only use the GRIP FRAME SCREW with the following models: Bisley™ Large Frame Bisley™ Small Frame New Model Blackhawk® New Model SingleSix™ Old Army™, .45 Super Blackhawk®, .44 Mag Super Blackhawk® Hunter, .44 Mag Vaquero™
- Ensure that the firearm is unloaded before installation or maintenance.
- Avoid using excessive force when installing or removing the screw to prevent damage.
- Always wear safety glasses when working with firearms to protect your eyes from debris.
- Keep hands and tools clear of moving parts during installation.

## Instructions for Installation and Usage

### 1. Preparation

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a screwdriver compatible with the GRIP FRAME SCREW.

### 2. Installation

- Locate the grip frame area of your firearm.
- Align the GRIP FRAME SCREW with the designated hole in the grip frame.
- Gently insert the screw and handtighten it to ensure proper alignment.
- Use the screwdriver to securely tighten the screw without overtightening.
- Verify that the grip is firmly attached and does not wobble.

### 3. PostInstallation Check

- Inspect the installation to ensure there are no gaps or misalignments.
- Test the grip by holding the firearm to ensure it feels secure and stable.

### 4. Maintenance

- Regularly check the GRIP FRAME SCREW for tightness and signs of wear.
- If necessary, repeat the installation process to ensure secure fitting.

## **Disposal Instructions**

- Dispose of the GRIP FRAME SCREW responsibly in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options where available.

## **Contact Information for Further Support**

For any inquiries regarding safety, installation, or product compatibility, please refer to the manufacturer's website or contact the designated support service. Always ensure to have the product details on hand for efficient assistance.

By following these guidelines and instructions, you can ensure a safe and enjoyable experience with the GRIP FRAME SCREW, AFRONT, SS. Thank you for your attention to safety and compliance with the EU General Product Safety Regulation.

# Säkerhetsinstruktioner för GRIP FRAME SCREW, AFRONT, SS

## Introduktion

Tack för att du valt GRIP FRAME SCREW, AFRONT, SS. Denna produkt är designad för att förbättra din upplevelse med din Rugerpistol. För att säkerställa säker användning och långvarig prestanda, vänligen följ dessa säkerhetsinstruktioner noggrant.

## Allmänna säkerhetsriktlinjer

- Använd produkten endast enligt anvisningarna.
- Kontrollera att produkten är i gott skick före användning.
- Förvara produkten utom räckhåll för barn och sårbara grupper.
- Rapportera eventuella skador eller defekter omedelbart.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

## Specifika säkerhetsåtgärder för användning

- Använd alltid skyddsglasögon och handskar vid installation.
- Kontrollera att alla skruvar är korrekt åtdragna innan användning.
- Undvik att använda produkten om du är osäker på dess integritet.
- Använd produkten endast med kompatibla modeller (se nedan).

## Kompatibla modeller

- Bisley™ Större Ram
- Bisley™ Mindre Ram
- Ny Modell Blackhawk®
- Ny Modell SingleSix™
- Old Army™, .45
- Super Blackhawk®, .44 Mag
- Super Blackhawk® Hunter, .44 Mag
- Vaquero™

## Instruktioner för installation och användning

### 1. Förberedelse:

- Samla nödvändiga verktyg: skruvmejsel och eventuellt en momentnyckel.
- Kontrollera att alla delar är rena och torra.

### 2. Installation:

- Ta bort den gamla skruven (om tillämpligt) med hjälp av skruvmejseln.
- Placera GRIP FRAME SCREW, AFRONT, SS på rätt plats.
- Åtdra skruven försiktigt till rätt moment för att undvika skador.

### 3. Användning:

- Kontrollera skruvens åtdragning efter första användning och regelbundet därefter.
- Använd produkten enligt instruktionerna för din specifika Rugermodell.

## **Avfallshantering**

- Kassera produkten enligt lokala föreskrifter för avfallshantering.
- Återvinn eventuella metallkomponenter om möjligt.

## **Kontaktinformation för ytterligare support**

För frågor eller mer information, vänligen kontakta tillverkaren eller din återförsäljare. Se till att ha produktens serienummer och inköpsinformation tillgänglig.

Genom att följa dessa instruktioner kan du säkerställa en säker och effektiv användning av din GRIP FRAME SCREW, AFRONT, SS. Tack för att du bidrar till en säker användning av produkter.