

GRIP FRAME SCREW, C-BOTTOM, SS - GRIP FRAME SCREW, C-BOTTOM FITS RUGER REVOLVERS SS

FITS: Bisley™ Large Frame; Bisley™ Small Frame; New Model Blackhawk®; New Model Single-Six®; Old Army, .45; Super Blackhawk®, .44 Mag; Super Blackhawk® Hunter, .44 Mag; Vaquero®



Attributes

- Name: GRIP FRAME SCREW, C-BOTTOM FITS RUGER REVOLVERS SS
- Manufacturer: RUGER
- Product no.: 780022010
- Mfr. No.: KXR01900
- Make: Ruger
- Model: Blackhawk
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for GRIP FRAME SCREW, CBOTTOM, SS](#)
- [Svenska: Säkerhetsinstruktioner för GRIP FRAME SCREW, CBOTTOM, SS](#)

Safety Instruction Guide for GRIP FRAME SCREW, CBOTTOM, SS

Introduction

Thank you for choosing the GRIP FRAME SCREW, CBOTTOM, SS. This product is designed to enhance the functionality of your Ruger revolvers. To ensure safe and effective use, please read this safety instruction guide carefully. It includes important safety guidelines, precautions, and instructions for installation and usage.

General Safety Guidelines

- Ensure that the product is suitable for your specific model of Ruger revolver. The GRIP FRAME SCREW, CBOTTOM, SS is compatible with the following models:
 - Bisley™ Large Frame
 - Bisley™ Small Frame
 - New Model Blackhawk®
 - New Model SingleSix®
 - Old Army, .45
 - Super Blackhawk®, .44 Mag
 - Super Blackhawk® Hunter, .44 Mag
 - Vaquero®
- Always handle firearms responsibly and in accordance with local laws and regulations.
- Keep the product and all related components out of reach of children and unauthorized users.
- Inspect the product for any defects or damage before installation. If any issues are found, do not use the product.
- Follow all instructions provided in this guide to minimize risks associated with improper use.

Specific Safety Precautions for Use

- Use protective eyewear when installing or handling the GRIP FRAME SCREW to prevent injury from falling or flying debris.
- Avoid using excessive force during installation to prevent damage to the screw or the firearm.
- Never attempt to modify the GRIP FRAME SCREW. Modifications can lead to unsafe conditions.
- If you experience difficulty during installation, consult a qualified gunsmith for assistance.
- Regularly check the integrity of the screw after installation to ensure it remains secure.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction before beginning installation.
- Gather the necessary tools, including a screwdriver that fits the screw head properly.

2. Installation Steps:

- Locate the grip panel on your Ruger revolver where the GRIP FRAME SCREW will be installed.
- Remove the existing screw if applicable, and set it aside.
- Align the GRIP FRAME SCREW with the screw hole in the grip frame.
- Insert the screw and turn it clockwise until it is snug. Do not overtighten.
- Reattach the grip panel securely, ensuring it fits properly without gaps.

3. PostInstallation:

- Once installed, check that the grip is secure and does not wobble.
- Test the function of the revolver to ensure everything operates smoothly.

Disposal Instructions

- Dispose of the GRIP FRAME SCREW in accordance with local regulations regarding metal waste.
- Do not dispose of the product in general household waste. Instead, consider recycling options available in your area.

Contact Information for Further Support

For any further assistance or inquiries regarding the GRIP FRAME SCREW, please refer to the contact information provided with your purchase. Ensure you have the product details available when reaching out for support.

By following these safety instructions, you can ensure the safe and effective use of the GRIP FRAME SCREW, CBOTTOM, SS with your Ruger revolvers. Thank you for prioritizing safety in your firearm practices.

Säkerhetsinstruktioner för GRIP FRAME SCREW, CBOTTOM, SS

Introduktion

Tack för att du valt GRIP FRAME SCREW, CBOTTOM, SS. Detta produktdokument innehåller viktiga säkerhetsanvisningar och riktlinjer för korrekt installation och användning av produkten. Vänligen läs och följ dessa instruktioner noggrant för att säkerställa en säker och effektiv användning.

Allmänna säkerhetsriktlinjer

- Produktsäkerhet är av högsta prioritet. Var medveten om att felaktig användning kan leda till skador.
- Kontrollera att produkten är i gott skick innan användning. Om du upptäcker några skador, använd inte produkten.
- Förvara produkten utom räckhåll för barn och sårbara grupper.
- Rapportera eventuella farliga produkter eller olyckor till lämpliga myndigheter.
- Håll dig informerad om återkallelser och säkerhetsuppdateringar via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd alltid skyddsglasögon och handskar när du installerar eller hanterar produkten.
- Kontrollera att skruven är korrekt installerad innan du använder den i din revolver.
- Undvik att använda produkten om du är osäker på installationsprocessen. Sök hjälp från en kvalificerad tekniker.
- Följ alltid tillverkarens rekommendationer för kompatibilitet med specifika modeller.

Instruktioner för installation och användning

1. Förberedelse:

- Se till att du har rätt verktyg för installationen, inklusive en skruvmejsel som passar skruvens huvud.
- Rengör området där skruven ska installeras för att säkerställa en bra passform.

2. Installation:

- Ta bort den gamla skruven om det är nödvändigt.
- Placera GRIP FRAME SCREW, CBOTTOM, SS i det avsedda hålet.
- Skruva in skruven försiktigt tills den sitter ordentligt men undvik att överdra den, vilket kan skada materialet.

3. Användning:

- När skruven är korrekt installerad, kontrollera att den sitter fast.
- Använd din revolver enligt tillverkarens instruktioner och se till att alla delar är korrekt monterade.

Avfallsanvisningar

- Avfallshantering av produkten ska ske i enlighet med lokala föreskrifter.
- Släng inte produkten i hushållssoporna. Kontakta din lokala avfallshantering för information om korrekt återvinning eller bortskaffande av metallskruvar.

Kontaktinformation för vidare support

För frågor eller ytterligare information, vänligen kontakta din återförsäljare eller tillverkare. Se till att ha produktens modellnummer till hands för snabbare hjälp.

Tack för att du följer dessa säkerhetsinstruktioner. Din säkerhet är viktig för oss!