

RUGER® M77® BEAD FRONT SIGHT HIGH - BEAD FRONT SIGHT HIGH .328" FOR RUGER M77 MARK II BRASS

FITS: M77® Bolt Action; M77® MK II Standard, .375, .416; M-77® MK II All-Weather®, Sporter; No. 1 - Common Parts Brass bead sight with detent hole in the rear.



Attributes

- Name: BEAD FRONT SIGHT HIGH .328" FOR RUGER M77 MARK II BRASS
- Manufacturer: RUGER
- Product no.: 780077017
- Mfr. No.:
- Color: Gold
- Height: .406
- Make: Ruger
- Material: Brass
- Model: M77,M77 Mark II,No. 1
- Style: Blade
- Delivery weight: 0.005kg
- Shipping height: 3mm
- Shipping width: 89mm
- Shipping length: 152mm
- UPC: MPF06700-328

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: RUGER® M77® Bead Front Sight High Safety Instruction Guide](#)
- [Svenska: Säkerhetsanvisningar för RUGER® M77® BEAD FRONT SIGHT HIGH](#)

RUGER® M77® Bead Front Sight High Safety Instruction Guide

Introduction

Thank you for choosing the RUGER® M77® Bead Front Sight High. This guide provides essential safety information and instructions for the safe use and installation of your new front sight. Please read this guide carefully and keep it for future reference.

General Safety Guidelines

- Ensure that the front sight is compatible with your specific firearm model before installation.
- Always handle firearms with care and in accordance with local laws and regulations.
- Do not use the front sight if it appears damaged or defective.
- Keep this product out of reach of children and unauthorized users.
- Always store your firearm in a secure location when not in use.

Specific Safety Precautions for Use

- Only use the RUGER® M77® Bead Front Sight High with the specified models: M77® Bolt Action, M77® MK II Standard, .375, .416, M77® MK II AllWeather®, Sporter, and No. 1.
- Ensure that the firearm is unloaded before attempting to install or adjust the front sight.
- Follow all manufacturer instructions for your firearm when installing the front sight.
- Avoid making adjustments to the front sight while the firearm is loaded or in a potentially dangerous situation.
- Regularly inspect the front sight for signs of wear or damage, and replace it if necessary.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your workspace is clean and free of distractions.
- Gather all necessary tools for installation, including a screwdriver and any other required instruments.

2. Installation:

- Verify that the firearm is unloaded.
- Remove the existing front sight if applicable, following the manufacturer's instructions.
- Align the RUGER® M77® Bead Front Sight High with the mounting hole on the firearm.
- Secure the front sight in place using the appropriate screws or fasteners.
- Ensure that the sight is firmly attached and does not wobble.

3. Usage:

- Familiarize yourself with the operation of your firearm and how the front sight affects aiming.
- Practice safe handling and shooting techniques at all times.
- Regularly check the alignment and condition of the front sight during use.

Disposal Instructions

- Dispose of the product in accordance with local regulations for electronic and metallic waste.
- Do not dispose of the product in regular household waste.

- If the product is damaged or no longer usable, ensure it is securely stored until proper disposal can be arranged.

Contact Information for Further Support

For any inquiries regarding safety, usage, or installation, please contact the manufacturer or your local authorized dealer.

Conclusion

By following these safety instructions and guidelines, you can ensure the safe and effective use of your RUGER® M77® Bead Front Sight High. Always prioritize safety and responsibility when handling firearms and related accessories. Thank you for your attention to these important safety measures.

Säkerhetsanvisningar för RUGER® M77® BEAD FRONT SIGHT HIGH

Introduktion

Tack för att du valt RUGER® M77® BEAD FRONT SIGHT HIGH. Denna produkt är utformad för att ge ökad precision och säkerhet vid användning av din RUGER M77 Mark II. Vänligen läs noggrant igenom dessa säkerhetsanvisningar för att säkerställa en säker och korrekt användning av produkten.

Allmänna säkerhetsriktlinjer

- Säkerställ att produkten är i gott skick innan användning. Kontrollera för eventuella skador eller defekter.
- Använd alltid produkten i enlighet med tillverkarens anvisningar.
- Förvara produkten på en säker plats, utom räckhåll för barn och andra otillbörliga användare.
- Rapportera eventuella osäkra produkter eller olyckor till myndigheterna omedelbart.
- Håll dig informerad om eventuella återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd endast RUGER® M77® BEAD FRONT SIGHT HIGH med kompatibla vapenmodeller (M77® Bolt Action, M77® MK II Standard, .375, .416, M77® MK II AllWeather®, Sporter, No. 1).
- Kontrollera att fästet är ordentligt installerat innan du använder vapnet.
- Använd skyddsglasögon och hörselskydd vid skjutning.
- Undvik att rikta vapnet mot något du inte avser att skjuta på.
- Håll alltid fingret borta från avtryckaren tills du är redo att skjuta.

Instruktioner för installation och användning

1. Installation av sikte:

- Se till att ditt vapen är avsäkrat och att inga patroner finns i magasinet.
- Ta bort det gamla siktet om det finns ett.
- Fäst RUGER® M77® BEAD FRONT SIGHT HIGH på den avsedda platsen enligt tillverkarens specifikationer.
- Kontrollera att siktet sitter fast ordentligt och är i rätt position.

2. Användning av sikte:

- Justera siktet vid behov för att passa din skjutstil och avståndet till målet.
- När du siktar, se till att du har en stabil och säker position.
- Följ alltid säkerhetsprotokoll för skjutning.

Avfallshantering

- Kassera förpackningar och eventuella oanvända delar på ett miljövänligt sätt.
- Följ lokala föreskrifter för avfallshantering och återvinning av metall och plast.

Kontaktinformation för ytterligare support

För frågor eller support relaterat till RUGER® M77® BEAD FRONT SIGHT HIGH, vänligen kontakta tillverkaren eller återförsäljaren där produkten köptes.

Genom att följa dessa säkerhetsanvisningar kan du säkerställa en trygg och effektiv användning av din

RUGER® M77® BEAD FRONT SIGHT HIGH. Tack för att du bidrar till en säkrare användning av produkter!