

FIRING PIN STOP

FITS: Mark II™ .22 Standard & Target, .22; Mark II™ 22/45®, .22



Attributes

- Name: FIRING PIN STOP
- Manufacturer: RUGER
- Product no.: 780100043
- Mfr. No.: A03500
- Make: Ruger
- Model: Mark II
- Delivery weight: 0.005kg
- Shipping width: 83mm
- Shipping length: 146mm

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for FIRING PIN STOP](#)
- [Svenska: Säkerhetsinstruktioner för Firing Pin Stop Ruger](#)

Safety Instruction Guide for FIRING PIN STOP

Introduction

Thank you for choosing the FIRING PIN STOP for your Ruger Mark II™ firearms. This guide provides essential safety instructions to ensure the safe and effective use of the product. Please read and follow these instructions carefully to maintain your safety and the safety of others.

General Safety Guidelines

- Always handle firearms with care and respect.
- Ensure that the firearm is unloaded before installing or replacing any components.
- Keep the FIRING PIN STOP and other firearm parts out of reach of children and unauthorized users.
- Regularly inspect your firearm and its components for wear and damage.
- Report any unsafe products or incidents to the relevant authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the FIRING PIN STOP is compatible with your specific model of Ruger Mark II™ before installation.
- Do not use the FIRING PIN STOP if it shows signs of damage or wear.
- Always wear appropriate safety gear, including eye protection, when handling firearms.
- Avoid using the firearm in wet or damp conditions to prevent corrosion and malfunction.
- Ensure that the firearm is pointed in a safe direction during installation and usage.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is unloaded.
- Gather necessary tools for installation (if applicable).

2. Installation

- Remove the slide from the firearm according to the manufacturer's instructions.
- Carefully remove the old firing pin stop if applicable.
- Align the new FIRING PIN STOP with the designated area on the slide.
- Gently press or tap the FIRING PIN STOP into place until it is securely fitted.
- Reassemble the slide onto the firearm.

3. Usage

- Confirm that the FIRING PIN STOP is properly installed before using the firearm.
- Test the firearm in a safe environment to ensure proper function.
- Follow all standard operating procedures for handling and firing your firearm.

Disposal Instructions

- Dispose of any damaged or unused FIRING PIN STOP components in accordance with local regulations.
- Do not dispose of the product in regular household waste; check for recycling options available in your area.

Contact Information for Further Support

For any questions or concerns regarding the FIRING PIN STOP, please refer to the contact information provided by the manufacturer or retailer at the time of purchase. Ensure to have the product details ready for efficient assistance.

By following these guidelines, you can help ensure your safety and the safe operation of your Ruger Mark II™ firearm. Thank you for your attention to these important safety instructions.

Säkerhetsinstruktioner för Firing Pin Stop Ruger

Introduktion

Tack för att du valde Firing Pin Stop för din Ruger Mark II™. Denna produkt är avsedd att förbättra säkerheten och funktionen hos ditt vapen. Det är viktigt att du läser och följer dessa säkerhetsinstruktioner noggrant för att säkerställa en säker användning.

Allmänna säkerhetsriktlinjer

- Använd alltid skyddsglasögon och hörselskydd när du hanterar eller använder ditt vapen.
- Kontrollera att vapnet är oladdat innan du utför installation eller underhåll.
- Håll alltid vapnet riktat bort från personer och föremål när det hanteras.
- Förvara alltid ditt vapen på ett säkert ställe, oåtkomligt för barn och obehöriga.
- Rapportera alla osäkra produkter eller olyckor till myndigheterna.

Specifika säkerhetsåtgärder för användning

- Kontrollera Firing Pin Stop för eventuella skador eller defekter innan installation.
- Använd endast Firing Pin Stop som är avsedd för Ruger Mark II™ .22 Standard & Target och Mark II™ 22/45®.
- Följ alltid tillverkarens anvisningar för installation och användning.
- Undvik att överbelasta ditt vapen med ammunition som inte rekommenderas av tillverkaren.

Instruktioner för installation och användning

1. Förberedelser

- Se till att vapnet är oladdat och säkert.
- Samla nödvändiga verktyg för installationen.

2. Installation av Firing Pin Stop

- Ta bort den befintliga Firing Pin Stop från vapnet.
- Placera den nya Firing Pin Stop på rätt position.
- Följ tillverkarens anvisningar för att säkerställa korrekt installation.
- Kontrollera att Firing Pin Stop sitter ordentligt på plats innan du använder vapnet.

3. Användning

- Använd vapnet endast i enlighet med tillverkarens rekommendationer.
- Utför regelbundet underhåll och inspektion av vapnet och dess delar.

Avfallsanvisningar

- Avfall som uppstår från installation eller underhåll av Firing Pin Stop bör hanteras enligt lokala avfallsföreskrifter.
- Kasta inte bort defekta eller trasiga delar tillsammans med hushållsavfall. Kontakta lokala myndigheter för korrekt avfallshantering.

Kontaktinformation för vidare stöd

För frågor eller ytterligare information om säkerhet och användning av Firing Pin Stop, vänligen kontakta din lokala återförsäljare eller tillverkare.

Dessa säkerhetsinstruktioner är utformade för att följa EU:s allmänna produkt säkerhetsförordning (GPSR). Det är viktigt att du är medveten om potentiella risker och följer anvisningarna för att säkerställa en säker och effektiv användning av din produkt.