

SHOTGUN SHELL CATCHERS - PLASTIC/STEEL FITS 1100 & 11-87

[Shooting Accessories](#) > [Range Gear](#) > [Shell Catchers & Deflectors](#)

Plastic clip stops cases in the ejection port for the easy removal. No more bending/stooping to pick up cases or losing them to ranges with "If it hits the ground, it's ours" policies. Snaps easily to side of receiver just below the ejection port; snaps off when you need to cycle more than one round, as when shooting doubles.



Attributes

- Name: [PLASTIC/STEEL FITS 1100 & 11-87](#)
- Manufacturer: [BIRCHWOOD CASEY](#)
- Product no.: 869012110
- Mfr. No.: BC-41060
- Style: Brass Catcher
- Delivery weight: 0.009kg
- Shipping height: 1mm
- Shipping width: 102mm
- Shipping length: 122mm
- UPC: 029057410600

Item details

Made in USA

Table of Contents

- Startpage
- SHOTGUN SHELL CATCHERS PLASTIC/STEEL FITS 1100 & 1187 Safety Instruction Guide
- About Us

SHOTGUN SHELL CATCHERS PLASTIC/STEEL FITS 1100 & 1187 Safety Instruction Guide

Introduction

Thank you for choosing the SHOTGUN SHELL CATCHERS PLASTIC/STEEL FITS 1100 & 1187. This product is designed to enhance your shooting experience by preventing spent shotgun shells from falling to the ground. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always handle firearms with care and follow all safety protocols.
- Ensure that the shotgun is unloaded before installing or removing the shell catcher.
- Do not use the shell catcher if it appears damaged or malfunctioning.
- Keep the shell catcher out of reach of children and unauthorized users.
- Regularly inspect the shell catcher for wear and tear.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the shell catcher is securely attached to the shotgun before use.
- Avoid using the shell catcher in conditions where it may become dislodged, such as during rapid fire.
- Do not attempt to cycle more than one round with the shell catcher attached, as it may obstruct ejection.
- Always wear appropriate eye and ear protection while shooting.
- Be aware of your surroundings and ensure a safe shooting environment.

Instructions for Installation and Usage

Installation

1. Ensure the shotgun is unloaded and pointed in a safe direction.
2. Locate the ejection port on the shotgun.
3. Align the plastic clip of the shell catcher with the side of the receiver just below the ejection port.
4. Snap the shell catcher into place until you hear a click, indicating it is secure.
5. To remove, gently pull the shell catcher away from the receiver.

Usage

- Once installed, the shell catcher will hold spent shells in the ejection port for easy removal.
- When shooting doubles or cycling more than one round, snap off the shell catcher to allow for normal ejection.
- After shooting, remove the shell catcher and collect the shells for disposal or recycling.

Disposal Instructions

- Dispose of the shell catcher according to local regulations for plastic and metal waste.
- Do not dispose of the shell catcher in regular household waste.
- Check with local authorities for proper recycling options.

Contact Information for Further Support

For any questions or concerns regarding the SHOTGUN SHELL CATCHERS PLASTIC/STEEL FITS 1100 & 1187,

please refer to the contact information provided in the product packaging or manual.

Thank you for prioritizing safety and compliance with these guidelines. Enjoy your shooting experience!

About Us

Brownells Deutschland

**Brownells Deutschland - Einer der größten Lieferanten für Waffenteile,
Büchsenmacherwerkzeug & Schießsportzubehör**

Lahnstraße 1
24539 Neumünster
Deutschland

www.brownells-deutschland.de