

EJECTOR, UPPER/LH 687 410GA SF - BERETTA USA EJECTOR, UPPER/LH 687 410GA SF

[Shotgun Parts](#) > [Receiver & Action Parts](#) > [Ejector Parts](#) > [Ejectors](#)

FITS: S687, .410

EJECTOR, UPPER/LH 687 410GA SF



Attributes

- Name: [BERETTA USA EJECTOR, UPPER/LH 687 410GA SF](#)
- Manufacturer: [BERETTA USA](#)
- Product no.: 913301202
- Mfr. No.: C45542
- Model: S687
- Weapon type: Beretta
- Delivery weight: 0.015kg
- Shipping height: 1mm
- Shipping width: 89mm
- Shipping length: 89mm

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for EJECTOR, UPPER/LH 687 410GA SF](#)
- [About Us](#)

Safety Instruction Guide for EJECTOR, UPPER/LH 687 410GA SF

Introduction

Thank you for choosing the EJECTOR, UPPER/LH 687 410GA SF from Beretta USA. This guide provides important safety information and instructions to ensure the safe use of your product. Please read this document carefully before using the ejector.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always follow the manufacturer's instructions for use and maintenance.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Stay informed about product recalls and safety updates through the EU Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear when handling or using the ejector.
- Ensure that the ejector is properly installed before use.
- Avoid using the ejector in wet or damp conditions to prevent electrical hazards.
- Do not modify the ejector in any way that could compromise its safety.
- Be aware of your surroundings and ensure that no bystanders are in the vicinity during use.

Instructions for Installation and Usage

1. Installation:

- Read the instruction manual thoroughly before installation.
- Ensure that you have all the necessary tools and components for installation.
- Follow these steps for proper installation:
 1. Locate the installation area on your firearm.
 2. Align the ejector with the designated mounting points.
 3. Secure the ejector using the provided screws or fasteners.
 4. Doublecheck that the ejector is firmly attached and does not move.

2. Usage:

- Before using the ejector, ensure that your firearm is unloaded and pointed in a safe direction.
- Load your firearm as per the manufacturer's instructions.
- Operate the ejector according to the guidelines provided in the firearm's manual.
- After use, clean and inspect the ejector to ensure it is free from debris and functioning correctly.

Disposal Instructions

- Dispose of the ejector in accordance with local regulations.
- If the ejector is damaged or no longer functional, do not attempt to repair it.
- Take the ejector to a designated waste disposal facility that handles firearms components.

Contact Information for Further Support

For safety inquiries or additional support, please contact your local Beretta USA representative or visit the official website for more information.

Thank you for your attention to these safety guidelines. Your safety and satisfaction are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk