

BERETTA 486 20/28 GAUGE COCKING LEVER RIGHT HAND - BERETTA USA BERETTA 486 20/28 GAUGE COCKING LEVER RIGHT HAND

[Shotgun Parts](#) > [Bolt Parts](#) > [Cocking Parts](#) > [Cocking Levers](#)

BERETTA 486 20/28 GAUGE COCKING LEVER RIGHT HAND

NO IMAGE
AVAILABLE

Attributes

- Name: [BERETTA USA BERETTA 486 20/28 GAUGE COCKING LEVER RIGHT HAND](#)
- Manufacturer: [BERETTA USA](#)
- Product no.: 913500454
- Mfr. No.: C5F022
- Model: 486
- Weapon type: Beretta
- Delivery weight: 0.454kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for BERETTA 486 20/28 Gauge Cocking Lever Right Hand](#)
- [About Us](#)

Safety Instruction Guide for BERETTA 486 20/28 Gauge Cocking Lever Right Hand

Introduction

Thank you for choosing the BERETTA 486 20/28 Gauge Cocking Lever Right Hand. This product is designed for performance and reliability. To ensure your safety and the safety of others, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always handle firearms and related accessories with care and respect.
- Ensure that you are familiar with the product before use.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the product for any signs of wear or damage.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the cocking lever is properly installed before using the firearm.
- Do not attempt to use the cocking lever if it appears damaged or malfunctioning.
- Always ensure that the firearm is unloaded when installing or adjusting the cocking lever.
- Use only compatible accessories and parts with the BERETTA 486 model.
- Avoid using the cocking lever in wet or damp conditions to prevent rust and corrosion.
- Store the product in a dry and safe location when not in use.

Instructions for Installation and Usage

1. Installation

- Ensure that the firearm is completely unloaded.
- Remove the existing cocking lever if applicable.
- Align the new cocking lever with the designated slot on the firearm.
- Secure the cocking lever in place according to the manufacturer's specifications.
- Check the installation to ensure it is secure and properly positioned.

2. Usage

- Before using the firearm, perform a safety check to ensure it is functioning correctly.
- Use the cocking lever as instructed in the firearm's manual.
- Avoid excessive force when operating the cocking lever to prevent damage.
- Always point the firearm in a safe direction when using the cocking lever.

Disposal Instructions

- Dispose of the product in accordance with local regulations for hazardous waste.
- Do not dispose of the product in regular household waste.
- Contact local authorities or waste management services for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or additional support regarding the BERETTA 486 20/28 Gauge Cocking Lever Right

Hand, please consult the relevant customer service contact points in your region.

Thank you for your attention to these safety guidelines. Your safety is our priority, and we appreciate your commitment to responsible firearm use.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk