

BERETTA SO SERIES COCKING ROD LEVER - BERETTA USA BERETTA SO SERIES COCKING ROD LEVER

[Shotgun Parts](#) > [Bolt Parts](#) > [Cocking Parts](#) > [Cocking Levers](#)

BERETTA SO SERIES COCKING ROD LEVER

NO IMAGE
AVAILABLE

Attributes

- Name: [BERETTA USA BERETTA SO SERIES COCKING ROD LEVER](#)
- Manufacturer: [BERETTA USA](#)
- Product no.: 913500952
- Mfr. No.: C92217
- Weapon type: Beretta
- Delivery weight: 0.005kg
- Shipping height: 1mm
- Shipping width: 51mm
- Shipping length: 76mm

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for BERETTA SO SERIES COCKING ROD LEVER](#)
- [About Us](#)

Safety Instruction Guide for BERETTA SO SERIES COCKING ROD LEVER

Introduction

Thank you for choosing the BERETTA SO SERIES COCKING ROD LEVER. This guide provides essential safety instructions and information to ensure the safe use of your product. It is important to read and understand these guidelines before using the product to minimize any risks associated with its use.

General Safety Guidelines

- Ensure the product is used only for its intended purpose as described in this manual.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear. Do not use if damaged.
- Follow all local regulations and guidelines regarding the use of this product.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always wear appropriate safety gear when handling the cocking rod lever.
- Ensure the firearm is unloaded before attaching or detaching the cocking rod lever.
- Do not use the cocking rod lever if you are unfamiliar with its operation. Seek assistance from a qualified professional.
- Avoid using excessive force when operating the cocking rod lever to prevent injury or damage.
- Do not modify the cocking rod lever in any way that could compromise its safety or functionality.

Instructions for Installation and Usage

1. Installation

- Ensure that the firearm is in a safe and secure position.
- Align the cocking rod lever with the designated slot on the firearm.
- Gently insert the cocking rod lever until it is securely in place.
- Confirm that the cocking rod lever is fully engaged and does not move when pulled.

2. Usage

- Before using the firearm, ensure that the cocking rod lever is functioning correctly.
- To operate, pull back on the cocking rod lever smoothly and steadily.
- Once the firearm is cocked, check that the lever has returned to its original position.
- After use, remove the cocking rod lever if necessary and store it safely.

Disposal Instructions

- When the cocking rod lever reaches the end of its life cycle, dispose of it in accordance with local regulations for hazardous materials.
- Do not throw the product in regular household waste.
- Consider recycling options available in your area to minimize environmental impact.

Contact Information for Further Support

For any safety inquiries or further support, please consult your retailer or the official BERETTA USA website for

contact details specific to your region.

Thank you for your attention to these safety guidelines. Your safety and the safety of others depend on your adherence to these instructions.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk