

Gun Case, Large - GUN CASE, SMALL

[Shooting Accessories](#) > [Gun Storage](#) > [Gun Cases](#)

Secure Protection For Semi-Autos/Revolvers

Full-length hinge, padlock provision and two snap latches. Foam-lined interior.
For semi-autos/revolvers.



Attributes

- Name: [GUN CASE, SMALL](#)
- Manufacturer: [SMITH & WESSON](#)
- Product no.: 940000555
- Mfr. No.: 390320000
- Color: Blue
- Material: Hard
- Size: 12 3/4
- Style: Handgun
- Delivery weight: 0.454kg
- Shipping height: 74mm
- Shipping width: 216mm
- Shipping length: 328mm
- UPC: 022188138511

Item details

Made in USA

Table of Contents

- Startpage
- Gun Case Safety Instruction Guide
- About Us

Gun Case Safety Instruction Guide

Introduction

Thank you for choosing the Smith & Wesson Gun Case. This guide provides important safety instructions and guidelines to ensure the safe usage of the product. Please read this manual carefully before using the gun case to understand the potential hazards and how to avoid them.

General Safety Guidelines

- Ensure that the gun case is used only for its intended purpose, which is to store firearms such as handguns and revolvers.
- Always keep the gun case closed and locked when not in use to prevent unauthorized access.
- Store the gun case in a secure location, out of reach of children and vulnerable individuals.
- Regularly inspect the gun case for any signs of damage or wear. Do not use a damaged case.
- If you notice any defects or safety issues, discontinue use and report the issue to the manufacturer.

Specific Safety Precautions for Use

- Always use a padlock to secure the gun case when storing firearms.
- Avoid overloading the case; ensure that the total weight does not exceed the manufacturer's recommendations.
- Do not store firearms with ammunition in the gun case.
- Be cautious when opening the gun case to avoid pinching fingers in the hinges or latches.
- Ensure the foam lining is intact and free from debris to prevent damage to the firearms.

Instructions for Installation and Usage

1. Unpacking the Gun Case

- Carefully remove the gun case from its packaging.
- Inspect the case for any visible damage or missing parts.

2. Securing the Gun Case

- Close the case and engage both snap latches.
- Insert a padlock through the padlock provision to secure the case.

3. Storing Firearms

- Open the case and place the firearm(s) inside the foamlined interior.
- Ensure that the firearms are positioned securely and do not move around inside the case.

4. Closing the Gun Case

- After placing the firearms inside, close the lid of the gun case.
- Engage the snap latches and secure the padlock to prevent unauthorized access.

5. Transporting the Gun Case

- Hold the case securely by the handle when transporting.
- Ensure that the case is locked during transport to prevent accidental opening.

Disposal Instructions

- When the gun case is no longer needed, dispose of it in accordance with local regulations.
- If the gun case is damaged beyond repair, consider recycling the plastic components where possible.
- Do not dispose of the gun case in regular household waste.

Contact Information for Further Support

For any safety inquiries or concerns regarding the gun case, please reach out to the manufacturer or your local authority.

By following these guidelines, you can ensure the safe and effective use of your Smith & Wesson Gun Case. Thank you for prioritizing safety!

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se