

BB 6" Whiffie - BUBBA Ultra Flex Tapered Flex Fillet Knife

The 6" Ultra Flex Tapered Flex offers anglers a fillet knife with the ultimate flexibility. This extreme flexibility is ideal for detailed precision cutting. The super thin blade design allows for effortless maneuvering, so you can easily remove bones with no loss of meat. The 6" Ultra Flex Tapered Flex is an ideal knife for small pan fish.

NO IMAGE
AVAILABLE

Attributes

- Name: BUBBA Ultra Flex Tapered Flex Fillet Knife
- Manufacturer: BUBBA
- Product no.: EU1001329
- Mfr. No.: 1085876
- Color: Red
- Delivery weight: 0.249kg
- Shipping height: 64mm
- Shipping width: 119mm
- Shipping length: 348mm
- EAN/UPC: 6.6112E+11

Table of Contents

- [Startpage](#)
- [English: BUBBA BB 6" Whiffie BUBBA Ultra Flex Tapered Flex Fillet Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA BB 6" Whiffie BUBBA Ultra Flex Tapered Flex Filékniv](#)

BUBBA BB 6" Whiffie BUBBA Ultra Flex Tapered Flex Fillet Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA BB 6" Whiffie BUBBA Ultra Flex Tapered Flex Fillet Knife. This guide provides essential safety instructions to ensure your safe and effective use of the knife. Please read this manual carefully before use.

General Safety Guidelines

- Always use the knife for its intended purpose.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife for any damage before use. Do not use if the blade is damaged or dull.
- Ensure that you are in a safe and stable environment when using the knife.
- Use appropriate personal protective equipment, such as cutresistant gloves, when handling the knife.
- Be aware of your surroundings and avoid distractions while using the knife.
- Store the knife securely in its sheath when not in use to prevent accidental injury.

Specific Safety Precautions for Use

- When filleting fish, always cut away from your body and keep your fingers clear of the blade.
- Do not attempt to catch or hold fish while using the knife.
- Avoid using excessive force when cutting; let the blade do the work.
- Do not use the knife for tasks other than filleting fish, such as prying or twisting.
- If the knife slips during use, maintain a safe distance from the blade to avoid injury.
- Always clean the knife after use to maintain hygiene and prevent corrosion.

Instructions for Installation and Usage

1. Before First Use:

- Remove the knife from its packaging.
- Inspect the blade and handle for any defects.
- Wash the blade with warm soapy water and dry thoroughly.

2. Using the Knife:

- Hold the knife firmly by the handle.
- Position the fish securely on a stable cutting surface.
- Start at the tail end of the fish and make a shallow cut into the flesh.
- Glide the blade along the spine, using smooth, controlled motions.
- Remove any bones as necessary, ensuring that you do not apply excessive pressure.

3. After Use:

- Clean the knife with warm soapy water and dry it completely.
- Store the knife in its synthetic sheath to protect the blade and prevent accidents.

Disposal Instructions

- When the knife reaches the end of its life, dispose of it responsibly.
- Do not throw the knife in regular household waste.

- Contact your local waste management authority for guidance on disposing of sharp objects safely.

Contact Information for Further Support

For any safety inquiries or further information regarding the BUBBA BB 6" Whiffie BUBBA Ultra Flex Tapered Flex Fillet Knife, please refer to the appropriate contact point in your region.

By following these safety instructions, you can ensure a safe and enjoyable experience while using your BUBBA fillet knife. Always prioritize safety and responsible usage. Thank you for your attention to these guidelines.

Säkerhetsinstruktioner för BUBBA BB 6" Whiffie BUBBA Ultra Flex Tapered Flex Filékniv

Introduktion

Tack för att du har valt BUBBA BB 6" Whiffie BUBBA Ultra Flex Tapered Flex Filékniv. Denna filékniv är designad för att ge optimal flexibilitet och precision vid filéering av fisk. För att säkerställa en säker användning av produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på en stabil och säker yta.
- Håll kniven utom räckhåll för barn och sårbara grupper.
- Kontrollera knivens skick innan användning. Om bladet är skadat eller slitet, sluta använda det omedelbart.
- Var medveten om omgivningen och se till att ingen är i närheten när du använder kniven.
- Använd alltid kniven för dess avsedda syfte.

Specifika säkerhetsåtgärder för användning

- Använd alltid ett skärbräda som underlag för att förhindra skador på kniven och ytan.
- Håll kniven med ett fast grepp och var försiktig med bladets vassa kant.
- Skär alltid bort från kroppen för att minimera risken för skador.
- Använd skyddshandskar om du är osäker på ditt grepp.
- Rengör kniven omedelbart efter användning för att förhindra bakterietillväxt.

Instruktioner för installation och användning

1. Installation:

- Ingen installation krävs. Kniven är klar att använda direkt ur förpackningen.

2. Användning:

- Håll kniven med ett fast grepp i handtaget.
- Placera fisken på skärbrädan och säkerställ att den ligger stabilt.
- Använd den flexibla egenskapen hos kniven för att skära nära ben och skinn.
- Var försiktig när du skär i trånga utrymmen för att undvika att skada dig själv.

Avfallshanteringsinstruktioner

- Kassera kniven på ett säkert sätt om den är skadad eller inte längre behövs.
- Följ lokala föreskrifter för avfallshantering av vassa objekt.
- Återvinn förpackningen i enlighet med lokala återvinningsprogram.

Kontaktinformation för ytterligare stöd

För frågor angående säkerhet eller användning av produkten, vänligen kontakta den lokala återförsäljaren eller producenten.

Rapportering av osäkra produkter

- Om du upptäcker en osäker produkt, rapportera den till relevanta myndigheter.
- Håll dig informerad om återkallelser och säkerhetsuppdateringar via EU:s Safety Gateplattform.

Tack för att du tar dig tid att läsa dessa säkerhetsinstruktioner. Genom att följa dessa riktlinjer kan du säkerställa en säker och effektiv användning av din BUBBA BB 6" Whiffie BUBBA Ultra Flex Tapered Flex Filékniv.