

Electric Fillet Knives - Lithium Ion Cordless Fillet Knife Set, 4 Blades

[Emergency & Survival Gear](#) > [Knives](#)

This Lithium Ion Cordless Electric Fillet Knife is ergonomically designed to fit perfectly in your hand. We've stayed true to our roots by incorporating the iconic non-slip grip handle which allows you to cut through fish like butter. Our lithium ion battery has the longest run time of any electric fillet knife on the market so you can stack fillets until you're out of fish. The engineered ventilation has been designed to maximize motor transmission output giving you an incredible amount of torque. Included are four different blade styles — 7" E-FLEX, 9" E-FLEX, 9" E-STIFF and 12" E-STIFF — that reflect our legendary tapered flex and stiff fillet knives. These blades are constructed out of high carbon stainless-steel and coated with titanium nitride making them extremely corrosion resistant. We've also incorporated a safety lock and trigger guard for ultimate security. The electric fillet knife comes in a premium EVA molded carrying case which allows you to break apart the storage units for easy cleaning. This knife contains a secondary replacement battery, charging cord, and all batteries contain a battery life indicator so you can rest assured that you'll never run out of juice. This electric fillet knife is exactly what you've been looking for and it's ready to fillet any fish any time.

NO IMAGE
AVAILABLE

Attributes

- Name: [Lithium Ion Cordless Fillet Knife Set, 4 Blades](#)
- Manufacturer: [BUBBA](#)
- Product no.: EU1001357
- Mfr. No.: 1095705
- Color: Red
- Delivery weight: 1.86kg
- Shipping height: 94mm
- Shipping width: 159mm
- Shipping length: 432mm
- UPC: 661120416128

Table of Contents

- [Startpage](#)
- [BUBBA Electric Fillet Knife Safety Instructions](#)
- [About Us](#)

BUBBA Electric Fillet Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA Electric Fillet Knife Set. This product is designed to provide a safe and efficient way to fillet fish. Please read and follow these safety instructions carefully to ensure safe use and avoid potential hazards.

General Safety Guidelines

- Always ensure that the knife is turned off and unplugged when not in use.
- Keep the knife out of reach of children and vulnerable individuals.
- Use the knife only for its intended purpose; do not use it for cutting materials other than fish.
- Regularly inspect the knife and blades for any signs of damage or wear.
- In the event of a malfunction or damage, discontinue use immediately and seek professional assistance.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the work area is clean and free from clutter to prevent accidents.
- Always use the knife on a stable surface to avoid slipping.
- Use the safety lock feature when the knife is not in use.
- Wear protective gloves if necessary to avoid cuts while handling the knife or fish.
- Be aware of your surroundings and ensure that no one is within reach of the blade while in use.
- Do not attempt to change blades while the knife is plugged in or turned on.

Instructions for Installation and Usage

1. Charging the Knife:

- Before first use, charge the lithiumion battery using the provided charging cord.
- Ensure the knife is turned off during charging.
- The battery life indicator will show when charging is complete.

2. Changing Blades:

- Ensure the knife is turned off and unplugged before changing blades.
- Press the release button to detach the current blade.
- Select the desired blade and insert it until it clicks into place.

3. Using the Knife:

- Hold the knife with a firm grip on the nonslip handle.
- Position the fish securely on a cutting board.
- Turn on the knife using the ergonomic trigger.
- Use smooth, controlled motions to fillet the fish.
- Turn off the knife immediately after use and unplug it.

4. Cleaning the Knife:

- Allow the knife to cool down before cleaning.
- Detach the blade and wash it separately with warm, soapy water.
- Wipe the handle and body of the knife with a damp cloth.
- Dry all parts thoroughly before reassembling.

Disposal Instructions

- Dispose of the knife and its components according to local regulations.
- Do not dispose of the lithiumion battery in regular waste. Follow local guidelines for battery disposal.
- If the knife is damaged beyond repair, ensure it is safely disposed of to prevent accidents.

Contact Information for Further Support

For any inquiries or concerns regarding the safety and use of the BUBBA Electric Fillet Knife, please refer to the manufacturer's contact details provided in the product packaging.

By following these safety instructions, you can enjoy using your BUBBA Electric Fillet Knife Set with confidence. Thank you for your attention to safety!

About Us

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB
Box 99
793 22 Leksand
Sverige

www.brownells.se