

Electric Fillet Knives - Electric Fillet Knife Blade, 9"

This 9" E-STIFF replacement Blade fits both our 110V Electric Fillet Knife and Cordless Lithium Ion Electric Fillet Knife. It's made of a High Carbon Stainless Steel and chemically bonded with a ti-nitride coating to be extremely corrosion resistant. The 9" blade serrated edge and apposing bidirectional blades make filleting medium to large size fish effortlessly.

NO IMAGE
AVAILABLE

Attributes

- Name: Electric Fillet Knife Blade, 9"
- Manufacturer: BUBBA
- Product no.: EU1001360
- Mfr. No.: 1099593
- Color: Silver
- Delivery weight: 0.113kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 381mm
- UPC: 661120418849

Table of Contents

- [Startpage](#)
- [English: BUBBA Electric Fillet Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för BUBBA Elektrisk Filékniv](#)

BUBBA Electric Fillet Knife Safety Instructions

Introduction

Thank you for choosing the BUBBA Electric Fillet Knife. This guide provides important safety instructions and guidelines to ensure safe and effective use of your knife. Please read this document carefully before using the product.

General Safety Guidelines

- Always use the knife in accordance with the manufacturer's instructions.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife for any damage or wear before each use.
- Do not use the knife if it is damaged or malfunctioning.
- Ensure that the knife is used in a safe environment, free from distractions and hazards.
- Always unplug the knife when not in use or when changing blades.
- Follow all local regulations regarding the use of electric knives.

Specific Safety Precautions for Use

• Electrical Safety:

- Only use the knife with the specified voltage (110V).
- Ensure that the power cord is intact and free from damage.
- Do not operate the knife with wet hands or in wet environments.

• Blade Safety:

- Handle the blades with care to avoid cuts and injuries.
- Always use the protective sheath when the blade is not in use.
- Do not attempt to sharpen the blade manually; use only manufacturer-recommended methods.

• Operational Safety:

- Always cut away from your body to avoid accidental injury.
- Do not force the knife through tough materials; let the blade do the work.
- Use the knife only for its intended purpose—filleting fish.

Instructions for Installation and Usage

1. Installation:

- Unbox the knife and check all components.
- Ensure that the blade is securely attached before use.
- Plug the knife into a suitable electrical outlet.

2. Usage:

- Hold the knife firmly by the handle.
- Position the fish on a stable cutting surface.
- Turn on the knife using the power switch.
- Begin filleting by gently guiding the blade through the flesh of the fish.
- Use the serrated edge for better control and ease of cutting.
- Once finished, turn off the knife and unplug it from the outlet.

3. Maintenance:

- Clean the blade after each use with warm, soapy water.
- Dry the blade thoroughly before storing.
- Store the knife in a dry place, preferably in its protective sheath.

Disposal Instructions

- Dispose of the knife and its components in accordance with local regulations.
- Do not dispose of electrical components with regular household waste.
- Contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any safety inquiries, concerns, or to report unsafe products, please contact your local consumer safety authority or visit the EU Safety Gate platform for updates on recalls and safety alerts.

Please ensure you follow these safety guidelines to enjoy a safe and efficient experience with your BUBBA Electric Fillet Knife.

Säkerhetsinstruktioner för BUBBA Elektrisk Filékniv

Introduktion

Tack för att du har valt BUBBA Elektrisk Filékniv. Denna säkerhetsinstruktionsguide är utformad för att ge dig viktig information om säker användning, installation och avfallshantering av produkten. Vänligen läs dessa instruktioner noggrant innan du använder filékniven för att säkerställa säkerhet och effektivitet.

Allmänna Säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Håll filékniven utom räckhåll för barn och sårbara grupper.
- Kontrollera alltid att kniven är i gott skick innan användning.
- Använd skyddshandskar när du hanterar kniven för att minimera risken för skador.
- Rapportera eventuella skador eller defekter på produkten till återförsäljaren.

Specifika Säkerhetsåtgärder för Användning

- Använd endast kniven för det avsedda syftet, dvs. filéa fisk.
- Se till att arbetsytan är stabil och ren för att förhindra olyckor.
- Håll kniven borta från vattenkällor när den är ansluten till ström.
- Undvik att använda kniven när du är trött eller distraherad.
- Koppla alltid bort kniven från strömförsörjningen när den inte används.

Instruktioner för Installation och Användning

1. Installation

- Kontrollera att kniven är kompatibel med strömkällan (110V).
- Anslut kniven till en jordad eluttag för att säkerställa säker drift.
- Kontrollera att alla delar är korrekt monterade innan användning.

2. Användning

- Sätt på kniven genom att trycka på strömbrytaren.
- Håll kniven med ett fast grepp och använd den med sågad kant för att skära genom fisken.
- Filéa fisken i ett jämnt och kontrollerat tempo för att undvika olyckor.
- Stäng av kniven och koppla bort den från strömmen när du är klar.

Avfallsinstruktioner

- Avfallshantering av produkten ska ske i enlighet med lokala föreskrifter.
- Om produkten är trasig eller inte längre behövs, lämna den till en återvinningsstation för elektriskt avfall.
- Tänk på att skydda miljön genom att inte kasta produkten i hushållssoporna.

Kontaktinformation för Ytterligare Stöd

För frågor eller bekymmer angående säkerheten och användningen av BUBBA Elektrisk Filékniv, vänligen kontakta den lokala återförsäljaren eller besök tillverkarens officiella webbplats för mer information.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av din BUBBA Elektrisk Filékniv. Tack för att du prioriterar säkerhet och ansvar vid användning av elektriska verktyg.