

## S&W Nylon w/Blue Box

- Folding Knife
- 8Cr13MoV steel with 2.75" blade length and weighs 2.5 oz
- Glass filled nylon handle with G10 texture and bead blast blade coating
- Finger flipper, liner lock and thumbstud
- Pocket Clip

NO IMAGE  
AVAILABLE

### Attributes

- Name: M&P S&W Nylon w/Blue Box
- Manufacturer: M&P
- Product no.: EU1001513
- Mfr. No.: 1100066
- Color: Black
- Delivery weight: 0.073kg
- Shipping height: 18mm
- Shipping width: 31mm
- Shipping length: 67mm
- EAN/UPC: 6.6112E+11

# Table of Contents

- [Startpage](#)
- [English: M&P S&W Nylon Folding Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P S&W Nylon w/Blue](#)

# M&P S&W Nylon Folding Knife Safety Instructions

## Introduction

Thank you for choosing the M&P S&W Nylon Folding Knife. This guide provides essential safety instructions to ensure the safe use and handling of your knife. Please read this manual carefully before using the product.

## General Safety Guidelines

- Always keep the knife out of reach of children and vulnerable individuals.
- Ensure the knife is stored in a safe location when not in use.
- Inspect the knife for damage before each use. Do not use if damaged.
- Use the knife only for its intended purpose; do not use it for prying or as a tool for other functions.
- Always cut away from your body and keep your fingers clear of the blade.
- Be aware of your surroundings when using the knife to avoid accidental injury to yourself or others.
- If the knife becomes stuck while cutting, do not force it. Carefully remove it from the material.
- Always close the knife when not in use to prevent accidental cuts or injuries.

## Specific Safety Precautions for Use

- The blade is sharp; handle with care to prevent cuts.
- Use the finger flipper and thumb stud to open the knife safely.
- Ensure the liner lock is fully engaged before using the knife.
- Do not attempt to modify the knife in any way, as this may compromise safety.
- Avoid using the knife in wet or slippery conditions to maintain a firm grip.
- If the knife is dropped, inspect it thoroughly for any damage before reusing it.

## Instructions for Installation and Usage

### 1. Opening the Knife:

- Use the finger flipper or thumb stud to open the blade.
- Ensure the blade is fully extended and locked in place by the liner lock.

### 2. Using the Knife:

- Hold the knife firmly by the handle.
- Position the material to be cut safely on a stable surface.
- Cut away from your body, maintaining control of the knife at all times.

### 3. Closing the Knife:

- Ensure your fingers are clear of the blade.
- Press the liner lock to release the blade and carefully fold it back into the handle.

### 4. Cleaning and Maintenance:

- Clean the knife with a damp cloth after use. Avoid using harsh chemicals.
- Regularly check the blade for sharpness and damage. Sharpen or replace as necessary.

## **Disposal Instructions**

- Dispose of the knife responsibly. If the knife is damaged beyond repair, wrap it securely to prevent injury and discard it in accordance with local waste disposal regulations.
- Do not dispose of the knife in a manner that could pose a risk to others.

## **Contact Information for Further Support**

For safety inquiries or concerns, please refer to the manufacturer's website or customer support resources available in your region.

Thank you for prioritizing safety while using the M&P S&W Nylon Folding Knife. Enjoy your product responsibly!

# Säkerhetsinstruktioner för M&P S&W Nylon w/Blue

## Introduktion

Tack för att du har valt M&P S&W Nylon w/Blue. Denna produkt är designad för att ge användaren en säker och effektiv upplevelse. För att säkerställa säkerheten och livslängden på produkten, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

## Allmänna säkerhetsriktlinjer

- Använd produkten endast för det avsedda ändamålet.
- Förvara produkten på en säker plats, utom räckhåll för barn.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera omedelbart eventuella defekter eller skador till tillverkaren.
- Vid onlineköp, se till att produkten kommer från en pålitlig återförsäljare.

## Specifika säkerhetsåtgärder vid användning

- Använd alltid produkten med försiktighet för att undvika skador.
- Håll fingrarna borta från bladet när du öppnar och stänger kniven.
- Använd fingerflippern och tumknappen med försiktighet för att undvika oavsiktlig öppning.
- Använd kniven på en stabil yta för att förhindra olyckor.
- Undvik att använda kniven för uppgifter den inte är avsedd för, såsom att skära genom hårda material.

## Instruktioner för installation och användning

1. **Öppna kniven:** Använd fingerflippern för att öppna bladet. Se till att fingrarna hålls borta från bladets väg.
2. **Låsa bladet:** Kontrollera att liner lock är korrekt aktiverat för att säkerställa att bladet hålls på plats under användning.
3. **Stänga kniven:** Tryck på liner lock för att låsa upp bladet och stäng försiktigt kniven. Håll fingrarna borta från bladet.
4. **Fickklämma:** Använd fickklämman för att fästa kniven på ett bälte eller en ficka för säker förvaring.

## Avfallsinstruktioner

- Kasta inte produkten i hushållsavfall.
- Följ lokala riktlinjer för avfallshantering av metallprodukter.
- Om produkten är skadad och inte längre kan användas, se till att den återvinns på ett ansvarsfullt sätt.

## Kontaktinformation för vidare support

För frågor eller säkerhetsrelaterade ärenden, vänligen kontakta tillverkaren direkt. Se till att ha produktens modellnummer och inköpsinformation tillgänglig för att få bästa möjliga hjälp.

Vänligen följ dessa säkerhetsinstruktioner noggrant för att säkerställa en trygg och säker användning av M&P S&W Nylon w/Blue. Tack för att du bidrar till en säker användning av våra produkter.