

S&W Nylon w/Blue - S&W Nylon w/Blue Clam Pack

- Folding Knife
- 8Cr13MoV steel with 2.75" blade length and weighs 2.5 oz
- Glass filled nylon handle with G10 texture and bead blast blade coating
- Finger flipper, liner lock and thumbstud
- Pocket Clip

NO IMAGE
AVAILABLE

Attributes

- Name: S&W Nylon w/Blue Clam Pack
- Manufacturer: M&P
- Product no.: EU1001514
- Mfr. No.: 1100067
- Color: Black
- Delivery weight: 0.091kg
- Shipping height: 238mm
- Shipping width: 20mm
- Shipping length: 67mm
- UPC: 661120076094

Table of Contents

- [Startpage](#)
- [English: M&P S&W Nylon w/Blue Folding Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P S&W Nylon w/Blue](#)

M&P S&W Nylon w/Blue Folding Knife Safety Instructions

Introduction

Thank you for choosing the M&P S&W Nylon w/Blue Folding Knife. This guide provides essential safety instructions and guidelines to ensure the safe use and maintenance of your knife. Please read this manual carefully before use.

General Safety Guidelines

- Always handle the knife with care.
- Keep the knife out of reach of children and vulnerable individuals.
- Inspect the knife regularly for any signs of damage or wear. Do not use if damaged.
- Use the knife only for its intended purpose; do not use it for prying or as a tool for other tasks.
- Store the knife in a safe place when not in use, preferably in a sheath or protective case.

Specific Safety Precautions for Use

- Ensure the blade is fully deployed and locked before use.
- Use the finger flipper and thumb stud to open the knife safely.
- Always cut away from your body and keep your fingers clear of the blade.
- Do not attempt to modify the knife or its components.
- Be cautious of the blade's sharpness; always treat it as if it is sharp, even when closed.
- If the knife becomes stuck or difficult to open, do not force it; seek assistance.

Instructions for Installation and Usage

1. Opening the Knife:

- Use the finger flipper or thumb stud to open the blade.
- Ensure the blade locks into place securely before use.

2. Using the Knife:

- Hold the knife firmly by the handle with a secure grip.
- Use the knife for cutting tasks such as opening packages, cutting rope, or other similar tasks.
- Avoid using the knife for tasks it is not designed for, such as prying or hammering.

3. Closing the Knife:

- To close the knife, press the liner lock and fold the blade back into the handle.
- Ensure the blade is fully retracted before storing.

Disposal Instructions

- When the knife reaches the end of its life or is no longer safe to use, dispose of it responsibly.
- Do not throw the knife in regular waste. Instead, consider recycling the metal components where possible.
- If unsure about disposal, contact local waste management authorities for guidance.

Contact Information for Further Support

For any safety inquiries or further assistance regarding your M&P S&W Nylon w/Blue Folding Knife, please refer to the manufacturer's website or customer service resources.

By following these safety instructions, you can ensure a safe and enjoyable experience with your M&P S&W Nylon w/Blue Folding Knife. Remember to always prioritize safety and responsible usage.

Säkerhetsinstruktioner för M&P S&W Nylon w/Blue

Introduktion

Tack för att du valt M&P S&W Nylon w/Blue. Denna fällkniv är designad för att vara både funktionell och säker. För att säkerställa en trygg användning av produkten, vänligen läs igenom dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid produkten enligt tillverkarens anvisningar.
- Håll produkten utom räckhåll för barn och sårbara grupper.
- Kontrollera produkten regelbundet för skador eller slitage.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.
- Håll dig informerad om återkallelser via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Använd kniven endast för avsedda ändamål.
- Undvik att använda kniven på hårda ytor som kan skada bladet.
- Värna om din säkerhet genom att alltid använda kniven med försiktighet.
- Använd fingerflippern och tumknappen på ett kontrollerat sätt för att öppna kniven.
- Se till att liner locken är korrekt på plats innan du använder kniven.

Instruktioner för installation och användning

1. Öppna kniven:

- Använd fingerflippern eller tumknappen för att öppna kniven.
- Kontrollera att liner locken är låst i position innan användning.

2. Användning:

- Håll kniven med ett fast grepp.
- Använd kniven i en vinkel som minimerar risken för olyckor.
- Skär alltid bort från kroppen och andra personer.

3. Stänga kniven:

- Tryck på liner locken för att frigöra bladet.
- Vik försiktigt bladet tillbaka in i handtaget.

Avfallshantering

- Avlägsna kniven från användning om den är skadad.
- Kasta produkten på ett ansvarsfullt sätt i enlighet med lokala avfallsregler.
- Om produkten är defekt, kontakta återförsäljaren för vägledning kring återvinning eller avfallshantering.

Kontaktinformation för vidare stöd

För frågor eller mer information om säkerheten kring produkten, vänligen kontakta din återförsäljare eller tillverkare. Se till att ha produktens modellnummer till hands för att få bästa möjliga hjälp.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en trygg och effektiv användning av M&P S&W Nylon w/Blue. Tack för att du bidrar till en säker användning av våra produkter!