

Velocite Spring Assist Folding Knife - Clam - Velocite Spring Assist Folding Knife - Box

One of our lightest EDC pocket knives. This clip point pocket knife is built with a heavily textured grip and a spring-assisted opening mechanism for a smooth open every time. Solid, sturdy, and an extremely light composition make this knife the perfect addition for an on-the-go carry.

NO IMAGE
AVAILABLE

Attributes

- Name: Velocite Spring Assist Folding Knife - Box
- Manufacturer: M&P
- Product no.: EU1001756
- Mfr. No.: 1122573
- Delivery weight: 0.01kg
- UPC: 661120081036

Table of Contents

- [Startpage](#)
- [English: M&P Velocite Spring Assist Folding Knife Safety Instructions](#)
- [Svenska: Säkerhetsinstruktioner för M&P Velocite Spring Assist Folding Knife](#)

M&P Velocite Spring Assist Folding Knife Safety Instructions

Introduction

Thank you for choosing the M&P Velocite Spring Assist Folding Knife. This guide provides essential safety instructions to ensure the safe and effective use of your knife. Please read this guide carefully before use and keep it for future reference.

General Safety Guidelines

- Ensure that the knife is used only for its intended purpose as a cutting tool.
- Always handle the knife with care to avoid injury.
- Keep the knife out of reach of children and vulnerable individuals.
- Regularly inspect the knife for any signs of damage or wear. Do not use if damaged.
- Store the knife in a safe place when not in use, preferably in a protective sheath or case.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Always cut away from your body and keep your fingers clear of the cutting path.
- Use the finger flipper to open the knife safely. Do not force the blade open.
- Ensure the knife is fully opened and locked before use.
- Avoid using the knife for tasks it is not designed for, such as prying or twisting.
- Be cautious when using the knife in wet or slippery conditions.
- If the knife becomes difficult to operate, do not attempt to disassemble it. Contact a professional for assistance.

Instructions for Installation and Usage

1. Opening the Knife:

- Hold the knife firmly by the handle.
- Use your index finger to push the finger flipper located on the back of the blade.
- The springassisted mechanism will open the blade smoothly.

2. Using the Knife:

- Ensure you have a stable surface for cutting.
- Position the item you wish to cut securely.
- Use a steady hand to guide the blade through the material.

3. Closing the Knife:

- Once you have finished using the knife, ensure the blade is clear of any obstructions.
- Press the liner lock (located on the side of the handle) to release the blade.
- Carefully fold the blade back into the handle until it clicks into place.

Disposal Instructions

- Dispose of the knife responsibly. If the knife is damaged beyond repair, consider recycling the metal parts where possible.
- Follow local regulations for the disposal of sharp objects to prevent injury to others.

Contact Information for Further Support

For any safety inquiries or further assistance, please contact the manufacturer directly. Ensure you have the product details at hand when seeking support.

Note: This safety instruction guide is designed to comply with the EU General Product Safety Regulation (GPSR). It aims to provide clear and concise information to ensure the safe use of the M&P Velocite Spring Assist Folding Knife. Always prioritize safety and be aware of your surroundings when using this product.

Säkerhetsinstruktioner för M&P Velocite Spring Assist Folding Knife

Introduktion

Tack för att du valt M&P Velocite Spring Assist Folding Knife. Denna fickkniv är designad för att vara lätt, robust och enkel att använda. För att säkerställa en säker och effektiv användning, vänligen läs och följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd alltid kniven på ett ansvarsfullt sätt och för dess avsedda syfte.
- Håll kniven utom räckhåll för barn och andra sårbara grupper.
- Kontrollera kniven regelbundet för skador eller slitage. Använd inte en skadad kniv.
- Vid onlineköp, se till att köpa från auktoriserade återförsäljare som följer EU:s säkerhetsstandarder.
- Rapportera eventuella farliga produkter eller olyckor till relevanta myndigheter.

Specifika säkerhetsåtgärder vid användning

- Använd alltid kniven med en säker och stabil hand.
- Undvik att rikta kniven mot dig själv eller andra när du öppnar eller stänger den.
- Använd fingerflippern för att öppna kniven, och se till att bladet är helt utfällt innan du använder den.
- Förvara kniven i ett säkert läge när den inte används, helst i ett fodral eller en låda.
- Var medveten om att kniven kan bli hal när den är blöt eller smutsig. Torka av den innan användning.

Instruktioner för installation och användning

1. Öppna kniven:

- Håll kniven i en hand med bladet vänd bort från dig.
- Använd fingerflippern för att öppna kniven. Kniven har en fjäderassisterad mekanism för smidig öppning.

2. Stänga kniven:

- Tryck på låsmekanismen och vik bladet tillbaka in i handtaget.
- Se till att bladet är helt inuti handtaget innan du förvarar kniven.

3. Användning:

- Använd kniven för skärning av material som är avsett för knivens kapacitet.
- Undvik att använda kniven för att skära genom hårda material som metall eller sten.

Avfallsinstruktioner

- När kniven närmar sig slutet av dess livslängd, se till att den avyttras på ett säkert sätt.
- Kontakta lokala myndigheter för att få information om korrekt avfallshantering av metallprodukter.
- Återvinn kniven om möjligt, i enlighet med lokala återvinningsregler.

Kontaktinformation för vidare stöd

För frågor eller support relaterade till säkerhet och användning av M&P Velocite Spring Assist Folding Knife, vänligen kontakta din återförsäljare eller besök M&P:s officiella webbplats för mer information.

Tack för att du följer dessa säkerhetsinstruktioner och säkerställer en trygg användning av din kniv.