

Loading Gate Spring Cover Screw Marlin Smith & Wesson - Loading Gate Spring Cover Screw | Marlin, Smith & Wesson

[Vapensmide](#) > [Small Hardware](#) > [Metallskruvar](#)

The RPP Flyweight lever action Loading Gate greatly reduces the effort required to stoke your Rossi 95 It's a masterfully tuned, competition grade part right out of the gate. SASS approved.

Starting with a massive reduction in spring weight, the RPP gate requires only about 1.5 lbs. of force to open fully, while the factory loading gate can require in excess of 5 lbs.

Next, we redesigned the lever-action loading gate to offer substantially more clearance for cartridges, further reducing load effort. This is a significant benefit when loading fat, straight wall ammo like the Marlin 444. In fact, during testing we discovered that we could load a .444 dummy through the gate of a typical Marlin 336 .30-30, without benefit of the Model 444's magazine tube clearance bulge. That's first class leg room!

Finally, we paid very careful attention to the inside "feed lip" area of the gate, optimizing geometry to ease gate opening against an on-deck round, and offer smooth feeding, with perfect case head control. With every gate precisely CNC machined from solid bar stock and hand polished, consistent results are assured.

Material is 7075-T6 aluminum, the strongest grade available. Engineered for highly stressed air frames, 7075 has extraordinary fatigue strength for thousands of flex cycles without failure. When anodized, it has a surface hardness exceeding hardened steel, for excellent wear properties.

The Firearm Blog Review: Ranger Point Precision Cloverleaf Peep Sights + Flyweight Loading Gate Springs

RPP Flyweight Marlin Loading Gate Features:

- * Spring weight reduced by up to 70%
- * No tuning required, saving you time and hassle
- * Greatly increased cartridge clearance
- * No knife sharp edges
- * Easy loading and smooth, reliable feeding
- * Precisely machined from 7075-T6 aluminum billet and hard anodized for extreme durability
- * Available in black, gold, or clear anodized finish (silver color to closely match stainless rifles)
- * 10-15 minute installation time
- * Single Action Shooting Society (SASS) approved

NO IMAGE
AVAILABLE

INSTALLATION

A couple of good screwdrivers is all that's needed.

The gun will need to be partially disassembled - just go slow, and remember that each screw needs to return to its original home, so get a piece of cardboard box, draw an approximation of the receiver on it, and poke a hole in your drawing where each screw can rest until reassembly.

- 1) Clear the rifle & ensure the chamber and magazine are EMPTY.
- 2) Unscrew/remove the tang screw from the upper/rear receiver tang, and pull off the buttstock to the rear.
- 3) Partially open bolt/lever, remove lever pivot screw and slide lever out of the bottom of the receiver (no need to remove bolt)
- 4) De-cock the hammer with the safety disengaged. Push forward on the hammer spring bridge and pull or push out one side of its groove. This will free the hammer spring
- 5) Remove hammer pivot screw, bottom trigger plate screw and side support screws to free the trigger plate from the receiver.
- 6) Remove the trigger plate / lower tang from the bottom of the receiver (some gentle prying may be needed).
- 7) Pull the locking lug out of the bottom of the receiver and swing the carrier out of the receiver (no need to remove the carrier pivot screw)
- 8) Unscrew the loading gate spring (1" behind the loading gate opening) and install the new gate and screw it in

Reassemble in reverse order.

Produktinformation

- Namn: [Loading Gate Spring Cover Screw | Marlin, Smith & Wesson](#)
- Tillverkare: [RANGER POINT](#)
- Produktnr: EU2014804
- Tillv.nr.: 200
- Leveransvikt: 0.45kg
- Leveranshöjd: 2.54mm
- Leveransbredd: 6.35mm
- Leveranslängd: 6.35mm
- UPC: 850078134127

Innehållsförteckning

- [Startsida](#)
- [Säkerhetsinstruktioner för Loading Gate Spring Cover Screw](#)
- [Om oss](#)

Säkerhetsinstruktioner för Loading Gate Spring Cover Screw

Introduktion

Tack för att du valt RANGER POINT Loading Gate Spring Cover Screw. Denna produkt är designad för att förbättra prestandan och användarvänligheten hos din Marlin eller Smith & Wesson. För att säkerställa säker användning och långvarig funktionalitet, vänligen följ dessa säkerhetsinstruktioner noggrant.

Allmänna säkerhetsriktlinjer

- Använd produkten endast enligt tillverkarens anvisningar.
- Kontrollera alltid att vapnet är avstängt och tomt innan installation eller underhåll.
- Håll produkten utom räckhåll för barn och andra sårbara grupper.
- Rapportera eventuella osäkra produkter eller olyckor till relevanta myndigheter.
- Kontrollera regelbundet för återkallelseuppdateringar via EU:s Safety Gateplattform.

Specifika säkerhetsåtgärder för användning

- Kontrollera att alla delar är intakta och i gott skick innan användning.
- Använd alltid rätt verktyg för installation och underhåll.
- Undvik att använda produkten om du upplever några avvikelser i funktionalitet, såsom svårigheter att öppna eller stänga.
- Använd inte produkten med ammunition som inte är avsedd för din specifika modell.

Instruktioner för installation och användning

1. Verktyg som behövs:

- En uppsättning skruvmejslar.
- En bit kartong för att organisera skruvar.

2. Installation:

1. Rensa geväret och säkerställ att kammaren och magasinet är TOMMA.
2. Ta bort tangskruven från den övre/bakre mottagartang och dra av kolven bakåt.
3. Öppna bolt/kolv delvis, ta bort kolvpivotskruven och dra ut kolven från botten av mottagaren (det är inte nödvändigt att ta bort bolten).
4. Avlasta hammaren med säkerheten avaktiverad. Tryck framåt på hammarfjäderbron och dra eller tryck ut ena sidan av dess spår. Detta frigör hammarfjädern.
5. Ta bort hammarpivotskruven, bottenplattans skruv och sidostöds skruvar för att frigöra bottenplattan från mottagaren.
6. Ta bort bottenplattan/lägre tang från botten av mottagaren (viss försiktig prydning kan behövas).
7. Dra ut låsningsklacken från botten av mottagaren och sväng ut transportören från mottagaren (det är inte nödvändigt att ta bort transportörens pivotskruv).
8. Ta bort fjädern för laddningsporten (1 tum bakom öppningen) och installera den nya porten och skruva i den.
9. Montera tillbaka i omvänd ordning.

Avfallshantering

- Följ lokala föreskrifter för avfallshantering av metallprodukter.
- Kasta inte produkten i hushållsavfall. Kontakta lokala återvinningscentraler för korrekt avfallshantering.

Kontaktdetaljer för ytterligare support

För frågor eller ytterligare information, vänligen kontakta tillverkaren eller din återförsäljare. Se till att ha produktens serienummer och inköpsinformation tillgänglig för snabbare hjälp.

Genom att följa dessa säkerhetsinstruktioner kan du säkerställa en säker och effektiv användning av RANGER POINT Loading Gate Spring Cover Screw. Tack för att du bidrar till en säkrare användning av vapenprodukter.

Om oss

Brownells Sverige

Brownells Sverige - Världens största leverantör av Vapendelar, Vapensmide Verktyg & Skyttetillbehör

Brownells Sverige AB

Box 99

793 22 Leksand

Sverige

www.brownells.se