

# ClayCopter Target Dispenser

[Shooting Accessories](#) > [Targets & Accessories](#) > [Throwers](#)

The Caldwell ClayCopter Target Dispenser keeps targets within easy reach when using handheld ClayCopter launchers. Its simple, user-friendly end caps fit securely over the shipping tubes of any 90mm or 110mm ClayCopter targets. To reload, simply pull a target from the dispensing end cap with your fingers—quick and effortless. An adjustable shoulder strap is included, allowing you to keep both hands free to operate the launcher while ensuring targets are always close at hand for fast, efficient reloads.

NO IMAGE  
AVAILABLE

## Attributes

- Name: [ClayCopter Target Dispenser](#)
- Manufacturer: [CALDWELL](#)
- Product no.: EU2016833
- Mfr. No.: 1237308
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 198700005279

# Table of Contents

- [Startpage](#)
- [ClayCopter Target Dispenser Safety Instructions](#)
- [About Us](#)

# ClayCopter Target Dispenser Safety Instructions

## Introduction

Welcome to the safety instructions for the Caldwell ClayCopter Target Dispenser. This guide is designed to help you use the product safely and effectively. Please read these instructions carefully before using the ClayCopter Target Dispenser to ensure a safe experience.

## General Safety Guidelines

- Always supervise children when using the ClayCopter Target Dispenser.
- Ensure the product is used only for its intended purpose.
- Regularly inspect the dispenser for any signs of damage or wear.
- Do not use the dispenser if it is damaged or malfunctioning.
- Store the dispenser in a dry place away from direct sunlight and extreme temperatures.
- Follow all local laws and regulations regarding the use of clay targets and launchers.

## Specific Safety Precautions for Use

- Use the dispenser only with compatible 90mm or 110mm ClayCopter targets.
- Do not attempt to modify or repair the dispenser yourself.
- Always ensure that the area around you is clear of people and obstacles before launching targets.
- Wear appropriate safety gear, such as eye protection, when using the ClayCopter launcher.
- Keep fingers away from the dispensing end cap when pulling targets to avoid injury.
- Ensure that the shoulder strap is securely fastened when using the dispenser to prevent accidental drops.

## Instructions for Installation and Usage

### 1. Installation:

- Remove the ClayCopter Target Dispenser from its packaging.
- Ensure that the end caps are securely fitted over the shipping tubes of the ClayCopter targets.
- Adjust the shoulder strap to a comfortable length for easy carrying.

### 2. Usage:

- To load targets, insert the ClayCopter targets into the dispenser through the open end caps.
- To dispense a target, grasp the dispensing end cap firmly and pull the target out with your fingers.
- Always maintain a safe distance from others while launching targets.
- After use, store the dispenser in a safe location.

## Disposal Instructions

- Dispose of the ClayCopter Target Dispenser in accordance with local waste disposal regulations.
- If the dispenser is no longer usable, consider recycling materials where applicable.
- Do not dispose of the dispenser in fire, as it may cause harmful emissions.

## Contact Information for Further Support

For any questions or concerns regarding the ClayCopter Target Dispenser, please refer to the manufacturer's contact information provided with the product packaging. You can also check for updates or recall information on the EU's Safety Gate platform.

By following these safety instructions, you can enjoy a safe and effective experience with your Caldwell

ClayCopter Target Dispenser. Thank you for choosing our product!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)