

ClayCopter Surface-to-Air

[Shooting Accessories](#) > [Targets & Accessories](#) > [Throwers](#)

See why shooters are calling ClayCopter targets “the new way to clay.” These innovative, spinning prop-style targets are made from biodegradable, non-toxic materials and fly in ways traditional clays simply can’t replicate. The Caldwell ClayCopter Surface-to-Air™ Launcher is the most advanced ClayCopter launcher available. Portable and ultra-lightweight at under 10 lbs, it retains the core features of the original ClayCopter while adding true hands-free operation. Powered by the included Caldwell 12-volt Li-Ion battery pack, it delivers up to 300 launches on a single charge.

Packed with advanced capabilities, the Surface-to-Air features independently adjustable oscillation and wobble functions, allowing shooters to tailor the difficulty to their preference. To unlock its full potential, users can connect via Bluetooth and control the launcher with the free Caldwell Clays App from up to 100 yards away. App features include pairing up to 10 additional Surface-to-Air or Claymore Connect throwers, hands-free voice control, target pair presentations, customizable flurries, and more. Take your shooting sessions to the next level and fill the sky with ClayCopter targets using the Surface-to-Air™ Launcher.

NO IMAGE
AVAILABLE

Attributes

- Name: [ClayCopter Surface-to-Air](#)
- Manufacturer: [CALDWELL](#)
- Product no.: EU2016835
- Mfr. No.: 1222326
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 198700005651

Table of Contents

- [Startpage](#)
- [ClayCopter Surface to Air Safety Instructions](#)
- [About Us](#)

ClayCopter SurfacetoAir Safety Instructions

Introduction

Thank you for choosing the ClayCopter SurfacetoAir™ Launcher. This innovative product is designed to enhance your shooting experience. Please read and follow these safety instructions carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always ensure that the area around you is clear of people, animals, and obstacles before launching targets.
- Use the ClayCopter only in designated shooting areas that comply with local regulations.
- Always wear appropriate eye and ear protection when operating the launcher.
- Keep all parts of your body clear of the launcher during operation.
- Ensure that the launcher is securely positioned on a stable surface before use.
- Do not attempt to modify or repair the launcher yourself. Contact the manufacturer for assistance.
- Be aware of your surroundings and avoid distractions while using the launcher.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is not intended for use by children under the age of 18 without adult supervision.
- **Environmental Considerations:** Do not use the launcher in wet or windy conditions, as this may affect the performance and safety.
- **Battery Safety:**
 - Only use the provided Caldwell 12volt Lilon battery pack.
 - Do not expose the battery pack to extreme temperatures or direct sunlight.
 - Charge the battery only with the recommended charger.
- **Target Safety:**
 - Use only ClayCopter biodegradable targets as intended.
 - Do not attempt to launch any other type of target or projectile.

Instructions for Installation and Usage

1. Setup:

- Place the ClayCopter SurfacetoAir Launcher on a flat, stable surface.
- Ensure that the launcher is facing away from people and animals.

2. Powering the Launcher:

- Connect the Caldwell 12volt Lilon battery pack to the launcher.
- Ensure the battery is fully charged before use.

3. Connecting to the App:

- Download the Caldwell Clays App on your smartphone.
- Follow the app instructions to connect via Bluetooth to control the launcher.

4. Adjusting Settings:

- Use the app to adjust oscillation and wobble functions to your preference.
- You can set up to 10 additional SurfacetoAir or Claymore Connect throwers if needed.

5. **Launching Targets:**

- Load the biodegradable targets into the launcher.
- Use the app or voice control feature to initiate the launch.
- Stand at a safe distance while the targets are being launched.

6. **PostUse:**

- Disconnect the battery after use to preserve battery life.
- Store the launcher in a dry, cool place when not in use.

Disposal Instructions

- Dispose of the biodegradable targets in accordance with local waste disposal regulations.
- For the launcher and battery, follow local electronic waste disposal guidelines.
- Do not dispose of the battery in fire or water.

Contact Information for Further Support

For any inquiries or concerns regarding the ClayCopter SurfacetoAir Launcher, please refer to the manufacturer's contact details provided in the product packaging or user manual.

By following these safety instructions, you can ensure a safe and enjoyable experience with your ClayCopter SurfacetoAir Launcher. Always prioritize safety and compliance with local laws while using this product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk