50 BMG LOCK-N-LOAD SHELL HOLDER ADAPTER

Reloading > Shellholders & Shellplates

The Hornady 50 BMG Lock-N-Load Shell Holder Adapter allows you to reload any standard caliber ammunition on the Hornady Lock-N-Load 50 BMG press. The long ram stroke works well for reloaders who are loading longer cartridges.

Attributes

- Name: 50 BMG LOCK-N-LOAD SHELL HOLDER ADAPTER
- Manufacturer: HORNADY
- Product no.: 100031435
- Mfr. No.: 392172
- Náboje: 50 BMG
- Delivery weight: 0.168kg
- Shipping height: 38mm
- Shipping width: 38mm
- Shipping length: 146mm
- UPC: 090255921724

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for 50 BMG LockNLoad Shell Holder Adapter
- About Us

Safety Instruction Guide for 50 BMG LockNLoad Shell Holder Adapter

Introduction

Thank you for choosing the Hornady 50 BMG LockNLoad Shell Holder Adapter. This product is designed to allow you to reload any standard caliber ammunition on the Hornady LockNLoad 50 BMG press. To ensure safe and effective use of this product, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that you are familiar with the operation of your reloading press before using the shell holder adapter.
- Always wear appropriate personal protective equipment (PPE) when reloading ammunition, including safety glasses and hearing protection.
- Keep your workspace clean and organized to prevent accidents.
- Store all reloading components, including the shell holder adapter, in a safe and secure location away from children and unauthorized users.
- Regularly inspect your equipment for wear and damage before use.
- Always follow the manufacturer's instructions for your specific reloading press and components.

Specific Safety Precautions for Use

- Do not exceed the recommended load specifications for any ammunition you are reloading.
- Ensure that the shell holder adapter is securely attached to the reloading press before use.
- Avoid using the shell holder adapter for any purpose other than its intended use.
- Keep hands and clothing clear of moving parts during operation.
- If you experience any unusual noises or resistance while using the shell holder adapter, stop immediately and inspect the equipment.
- Do not attempt to modify or alter the shell holder adapter in any way.

Instructions for Installation and Usage

1. **Installation of the Shell Holder Adapter**
    - Unpack the shell holder adapter and inspect it for any damage.
    - Ensure your reloading press is turned off and unplugged.
    - Locate the shell holder slot on your Hornady LockNLoad 50 BMG press.
    - Insert the shell holder adapter into the slot, ensuring it is seated firmly.
    - Secure the adapter according to the manufacturer's instructions for your reloading press.
2. **Using the Shell Holder Adapter**
    - Prepare your reloading components according to standard reloading procedures.
    - Place the cartridge case into the shell holder adapter.
    - Follow the reloading press operation instructions to complete the reloading process.
    - After reloading, remove the cartridge case from the shell holder adapter and inspect it for any defects.

Disposal Instructions

- Dispose of the shell holder adapter in accordance with local regulations regarding metal waste.
- If the shell holder adapter is damaged or no longer usable, do not attempt to repair it. Dispose of it

responsibly.

Contact Information for Further Support

For inquiries or concerns regarding the safety and use of the Hornady 50 BMG LockNLoad Shell Holder Adapter, please contact the appropriate EUbased support contact. Ensure you have your product information and any relevant details ready for a more efficient response.

By following these guidelines, you can ensure a safer reloading experience with the Hornady 50 BMG LockNLoad Shell Holder Adapter. Always prioritize safety and compliance with local regulations while reloading ammunition.

About Us

Brownells Česká republika

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.cz