

# AIMPOINT STANDARD MOUNT

[Optics & Mounting](#) > [Rings, Mounts & Bases](#) > [Mount Sets](#)

## Rock-Solid Mounts With Patented Quick-Detach System

Quick-release lever-lock system clamps solidly to flattop rail and will not work loose even under heavy recoil—the more force acting on the lever, the tighter it locks. Depress the release tab to swing the lever open, and the mount easily lifts off the rifle. Adjustable with a flat head screwdriver or even a coin for an ultra-secure, no-slip fit on almost any Picatinny or Weaver-style rail, including over- or under-sized commercial rails. Lever may be configured to lock to the front or the rear to suit the operator's preference. Large locking bar on the side of the mount engages the maximum amount of rail area, while the crossbolt and two integral locking lugs ensure rock-solid engagement of rail slots to prevent movement under recoil. Five heavy duty steel hex head screws (three on top, two on bottom) clamp the vertically split ring halves together. Cutouts in the ring sides and in the base reduce weight without sacrificing strength. AD-68 Aimpoint Mount is designed for Aimpoint optics or similar aiming devices requiring a single, 30mm ring, including the Comp C3 and M2/ML2/M3/ML3 series. Available in four configurations to suit a variety of mounting needs. Standard co-witnesses "iron" sights near the center of the optic when mounted on an AR-15/M16/M4 with standard-height mil-spec sights.



## Attributes

- Name: [AIMPOINT STANDARD MOUNT](#)
- Manufacturer: [AMERICAN DEFENSE MANUFACTURING](#)
- Product no.: 100003650
- Mfr. No.: AD68STD
- Color: Matte Black
- Finish: Black
- Fits / Used For: -
- Height: .940"
- Make: AR-15
- Material: 6061 T6 Aluminum
- Number of Bases: 1-Piece
- Scope Tube Diameter: 30mm
- Size: Standard
- Style: Standard
- Delivery weight: 0.159kg
- Shipping height: 61mm
- Shipping width: 86mm
- Shipping length: 145mm
- UPC: 818503010101

## Item details

Made in USA

# Table of Contents

- Startpage
- AIMPOINT STANDARD MOUNT Safety Instruction Guide
- About Us

# AIMPOINT STANDARD MOUNT Safety Instruction Guide

## Introduction

Thank you for choosing the AIMPOINT STANDARD MOUNT. This guide provides essential safety instructions to ensure the proper and safe use of the product. Please read this guide thoroughly before using the mount.

## General Safety Guidelines

- Ensure that the mount is suitable for your specific firearm and intended use.
- Always follow the manufacturer's instructions for installation and usage.
- Regularly inspect the mount for signs of wear or damage.
- Ensure that the mount is securely fastened before each use.
- Keep the mount and all accessories out of reach of children and unauthorized users.
- Report any unsafe products or accidents to the relevant authorities.

## Specific Safety Precautions for Use

- **Recoil Management:** The mount is designed to withstand heavy recoil. However, ensure that it is properly installed to prevent loosening during use.
- **Installation Tools:** Use a flat head screwdriver or a coin to adjust the mount. Do not use excessive force which may damage the mount or the firearm.
- **Locking Mechanism:** Ensure the locking lever is configured to your preference (front or rear lock) and is fully engaged before use.
- **Weight Considerations:** The mount has been designed to reduce weight without sacrificing strength. Ensure that your firearm can support the mount and any attached optics.
- **Compatibility:** Confirm that the mount is compatible with your optic device, especially if using it with models like the Comp C3 and M2/ML2/M3/ML3 series.

## Instructions for Installation and Usage

### 1. Preparation:

- Gather required tools: a flat head screwdriver or a coin.
- Ensure the firearm is unloaded and pointed in a safe direction.

### 2. Mounting the Aimpoint Standard Mount:

- Place the mount on the desired location on the Picatinny or Weaverstyle rail.
- Adjust the lever to ensure it fits securely on the rail.
- Tighten the screws to clamp the vertically split ring halves together. Ensure that three screws are on top and two on the bottom.

### 3. Adjusting the Locking Lever:

- Determine whether you want the lever to lock to the front or the rear.
- Adjust the lever accordingly to suit your preference.

### 4. Attaching the Optic Device:

- Securely place the 30mm optic into the mount.
- Ensure that the optic is aligned properly for optimal viewing.

- Tighten the locking mechanism to secure the optic in place.

#### **5. Final Inspection:**

- Check that all screws are tightened and the mount is securely attached to the firearm.
- Perform a visual inspection to ensure there are no loose parts.

## **Disposal Instructions**

- Dispose of the AIMPOINT STANDARD MOUNT in accordance with local regulations.
- Do not dispose of the mount in regular household waste if it is damaged or broken.
- Check with local waste management authorities for proper disposal methods.

## **Contact Information for Further Support**

For any questions or concerns regarding the AIMPOINT STANDARD MOUNT, please consult the manufacturer's website or customer service for assistance.

By following these safety instructions, you can ensure the safe and effective use of your AIMPOINT STANDARD MOUNT. Thank you for your attention to safety.

# About Us

## Brownells Austria

**Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

[www.brownells.at](http://www.brownells.at)