

MAGNUM MELTER FURNACE - LEE PRECISION LEE MAGNUM MELTER

[Reloading](#) > [Bullet Casting](#) > [Casting Furnaces & Accessories](#)

The Lee Magnum Melter features a large 4" diameter pot, allowing easy access for the ladle caster. Same high efficiency design that has made Lee pots the most popular. Melt time is less than 20 minutes with just 700 watts. 20 pound capacity for even the longest casting sessions. Melter is capable of reaching 900 degrees Fahrenheit.



Attributes

- Name: [LEE PRECISION LEE MAGNUM MELTER](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 100053073
- Mfr. No.: 90949
- Delivery weight: 1.61kg
- UPC: 734307909499

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for the Lee Magnum Melter Furnace
- About Us

Safety Instruction Guide for the Lee Magnum Melter Furnace

Introduction

Thank you for choosing the Lee Magnum Melter Furnace. This product is designed to provide efficient and safe melting for your casting needs. Please read this safety instruction guide carefully to ensure safe operation and maintenance of the furnace.

General Safety Guidelines

- Always follow the manufacturer's instructions for safe use.
- Ensure the furnace is used in a wellventilated area to avoid the buildup of fumes.
- Keep the furnace out of reach of children and pets.
- Regularly check the product for any signs of damage or wear.
- Be aware of your surroundings and ensure that flammable materials are kept away from the furnace.
- If you experience any issues while using the furnace, discontinue use and consult the manufacturer.

Specific Safety Precautions for Use

• Electrical Safety:

- Ensure the furnace is connected to a power supply that matches the specified voltage (110120V).
- Do not use extension cords or adapters that are not rated for the furnace.
- Avoid operating the furnace with wet hands or in damp conditions.

• Heat Safety:

- The furnace can reach temperatures up to 900 degrees Fahrenheit. Use heatresistant gloves when handling the pot or ladle.
- Allow the furnace to cool completely before handling or cleaning.

• Material Safety:

- Only use materials recommended by the manufacturer for melting.
- Avoid mixing different metals unless specified, as this may cause hazardous reactions.

• Emergency Preparedness:

- Keep a fire extinguisher rated for electrical fires nearby while using the furnace.
- Familiarize yourself with the emergency shutdown procedures.

Instructions for Installation and Usage

• Installation:

- Place the furnace on a stable, heatresistant surface away from flammable materials.
- Ensure the area around the furnace is clear and wellventilated.

• Usage:

- Plug the furnace into a suitable electrical outlet.
- Preheat the furnace according to the manufacturer's instructions.

- Use the ladle caster to pour molten material safely.
- Monitor the melting process closely and never leave the furnace unattended while in use.

- **PostUsage:**

- Turn off the furnace and unplug it once you have finished using it.
- Allow the furnace to cool before attempting to clean or store it.

Disposal Instructions

- Dispose of the furnace according to local regulations.
- If the furnace is damaged or no longer functional, contact your local waste management facility for guidance on safe disposal.
- Do not dispose of the furnace in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the Lee Magnum Melter Furnace, please refer to the manufacturer's contact information provided with your product. Remember to report any unsafe conditions or accidents to the appropriate authorities.

Thank you for taking the time to read this safety instruction guide. Your safety is our priority, and we hope you enjoy using the Lee Magnum Melter Furnace responsibly and efficiently.

About Us

Brownells Europe

Brownells Europe - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

P.O.Box 4300
Warwick
CV34 9BR

www.brownells.eu