

# ATACR 4-16X42MM F1 FFP RIFLE SCOPES - ATACR 4-16X42MM FFP ILLUMINATED MOA-XT RETICLE BLACK

[Optics & Mounting](#) > [Scopes](#) > [Rifle Scopes](#)

If you need something compact yet powerful, the ATACR 4-16x42 F1 delivers. The fully multi-coated ED glass lenses within are stunning. Adjustments are standard with the Nightforce low profile ZeroHold feature, and available in .1 Mrad increments (12 Mils per revolution). A capped windage adjustment helps prevent accidental adjustment in the field. The parallax adjustment is marked with approximate numbered distances. The eyepiece features enhanced engraving, an integrated Power Throw Lever (PTL) and an XtremeSpeed thread for making a fast diopter adjustment. All of these features are paired with intelligent, Nightforce F1, first focal plane, reticles that provide for fast hold-off adjustments and precise ranging calculations. The ATACR 4-16x42 F1 sets a new standard in mid-powered optics.

NO IMAGE  
AVAILABLE

## Attributes

- Name: [ATACR 4-16X42MM FFP ILLUMINATED MOA-XT RETICLE BLACK](#)
- Manufacturer: [NIGHTFORCE](#)
- Product no.: 430105744
- Mfr. No.: C647
- Battery: CR-2032
- Click Value: 1/4 MOA
- Click Value: 1/4 MOA
- Eye Relief: 3.50"
- Finish: Black
- Focal Plane: First
- Illumination: Yes
- Length: 12.6"
- Max Magnification: 16x
- Min. Magnification: 4x
- Model Number: ATACR 4
- Objective Size: 42mm
- Reticle: MOA-XT
- Tube Size: 34mm
- Weight: 1.875 lbs
- Delivery weight: 1.542kg
- Shipping height: 152mm
- Shipping width: 133mm
- Shipping length: 584mm
- UPC: 847362020556

## Item details

Made in USA

This product contains a battery.

US export classification: 0A504.a

# Table of Contents

- Startpage
- ATACR 416X42MM F1 FFP RIFLE SCOPES Safety Instruction Guide
- About Us

# ATACR 416X42MM F1 FFP RIFLE SCOPES Safety Instruction Guide

## Introduction

Thank you for choosing the ATACR 416X42MM F1 FFP Rifle Scope. This guide provides essential safety instructions to ensure the safe use and maintenance of your product. Please read this document thoroughly before using the rifle scope to understand the safety guidelines and proper handling procedures.

## General Safety Guidelines

- Ensure that the rifle scope is used only for its intended purpose.
- Always handle the rifle scope with care to prevent damage.
- Keep the rifle scope out of reach of children and unauthorized users.
- Regularly inspect the scope for any signs of damage or wear.
- Use the rifle scope in accordance with local laws and regulations regarding firearms.
- If you experience any malfunction or damage, discontinue use immediately and seek assistance.

## Specific Safety Precautions for Use

- **Avoid Eye Injury:** Always use eye protection when using firearms equipped with this scope.
- **Secure Mounting:** Ensure that the scope is securely mounted to the rifle to prevent it from becoming loose during use.
- **Parallax Adjustment:** Make sure to adjust the parallax setting according to the distance of your target to ensure accurate aiming.
- **Illumination Caution:** When using the illuminated reticle, ensure that the brightness is set to a comfortable level to avoid eye strain.
- **Battery Safety:** Use only the specified CR2032 battery for illumination. Dispose of used batteries properly and keep them away from children.
- **Weather Conditions:** Avoid using the scope in extreme weather conditions that could impair visibility or damage the scope.

## Instructions for Installation and Usage

### 1. Mounting the Scope:

- Select a suitable mounting base for your rifle.
- Align the scope with the mounting rings and secure it according to the manufacturer's instructions.
- Ensure that the scope is level and properly aligned with the rifle.

### 2. Adjusting the Scope:

- Set the magnification to your desired level (4x to 16x).
- Adjust the windage and elevation settings using the provided turrets.
- Make sure to check the click values to ensure accurate adjustments.

### 3. Parallax Adjustment:

- Use the parallax adjustment feature to set the distance based on your target.
- Refer to the marked distances on the scope for guidance.

### 4. Illumination:

- To activate the illuminated reticle, turn the illumination dial to the desired brightness level.
- Turn off the illumination when not in use to conserve battery life.

#### **5. Diopter Adjustment:**

- Use the integrated Power Throw Lever (PTL) to quickly adjust the diopter for optimal focus.

## **Disposal Instructions**

- Dispose of the rifle scope and its components in accordance with local regulations.
- Do not dispose of electronic components, such as batteries, in regular household waste. Follow your local recycling guidelines for proper disposal.

## **Contact Information for Further Support**

For any inquiries regarding safety or product issues, please reach out to the designated EU contact point for assistance. Always refer to the manufacturer's website for the latest updates and support resources.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your ATACR 416X42MM F1 FFP Rifle Scope. Thank you for your attention to these important safety measures.

# About Us

## Brownells Norge

**Brownells Norge - Komplett utvalg av ladeutstyr, våpendeler, kuler, hylser, kikkerter, optikk og luftvåpen**

Heiveien 882  
4985 Vegårshei

[www.brownells.no](http://www.brownells.no)