

XL750 Progressive Reloading Machine for Rifle Calibers - Dillon XL750 Progressive Reloading Machine 204 RUGER

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

The Dillon XL750 is a high-speed progressive reloading machine designed to load common rifle and handgun cartridges, from 17 Hornet through the common belted magnum cartridges in rifle, and 32 ACP through 500 S&W in handgun. Machine height from the bench is 32" without the optional electric case feeder, 38 1/2" with the electric casefeeder installed. A die set has to be ordered separately. Other options shown, but not included: Casefeeder, Strong Mount, Bullet Tray, Powdercheck Die and Low Powder Sensor.

NO IMAGE
AVAILABLE

Attributes

- Name: [Dillon XL750 Progressive Reloading Machine 204 RUGER](#)
- Manufacturer: [DILLON](#)
- Product no.: EU2005301
- Mfr. No.: DI75001
- Cartridge: 204 Ruger
- Delivery weight: 5.5kg

Table of Contents

- [Startpage](#)
- [Dillon XL750 Progressive Reloading Machine Safety Instructions](#)
- [About Us](#)

Dillon XL750 Progressive Reloading Machine

Safety Instructions

Introduction

Thank you for choosing the Dillon XL750 Progressive Reloading Machine for Rifle Calibers. This guide provides essential safety instructions to ensure safe and effective use of your reloading machine. Please read this manual carefully before use to understand the safety precautions, installation instructions, and maintenance requirements.

General Safety Guidelines

- Always wear appropriate safety gear, including safety glasses and hearing protection, when operating the reloading machine.
- Keep the reloading area clean and free of obstructions to prevent accidents.
- Do not operate the machine while under the influence of drugs or alcohol.
- Ensure that all components are properly installed and secured before use.
- Store all reloading materials, including powder and primers, in a safe and secure location, away from children and pets.
- Keep the machine out of reach of children and unauthorized users.
- Regularly inspect the machine for any signs of wear or damage. Do not use if damaged.
- Follow all local laws and regulations regarding reloading and ammunition.

Specific Safety Precautions for Use

- Always use the correct caliber and type of components as specified for the Dillon XL750.
- Ensure that the machine is placed on a stable and level surface to prevent tipping.
- Do not overload the machine with components beyond its specified capacity.
- Avoid direct contact with hot surfaces during and after operation.
- Never leave the machine unattended while in operation.
- If a malfunction occurs, cease operation immediately and consult the troubleshooting section of the manual.
- Use caution when handling primers and powder to avoid accidental ignition.
- Dispose of any unused or expired reloading materials according to local regulations.

Instructions for Installation and Usage

Installation

1. **Choose a Location:** Select a stable, level surface for the reloading machine, ensuring there is adequate lighting and ventilation.
2. **Secure the Machine:** Use the Strong Mount to secure the machine to the surface, preventing movement during operation.
3. **Install the Electric Case Feeder (optional):** If using the electric case feeder, follow the manufacturer's instructions for installation.
4. **Set Up the Die Set:** Purchase the appropriate die set separately and install it according to the instructions provided with the die set.
5. **Check All Components:** Ensure that all parts are correctly assembled and securely fastened before beginning operation.

Usage

1. **Prepare Your Work Area:** Ensure that your work area is clean and organized. Gather all necessary materials, including brass cases, powder, primers, and bullets.

2. **Load Components:** Follow the specific instructions for loading each component into the machine, ensuring that you use the correct type and caliber.
3. **Adjust Settings:** Adjust the machine settings according to the specifications for the desired cartridge. Refer to the user manual for detailed instructions on adjustments.
4. **Start Reloading:** Begin the reloading process, closely monitoring the machine for any signs of malfunction or issues.
5. **Regularly Inspect:** Periodically check the machine during operation to ensure it is functioning correctly and safely.

Disposal Instructions

- Dispose of any unused or expired reloading materials according to local hazardous waste regulations.
- Do not dispose of primers and powder in regular trash. Follow local guidelines for proper disposal.
- Ensure that all metal and plastic parts of the machine are recycled or disposed of in accordance with local regulations.

Contact Information for Further Support

For any safety inquiries, product support, or to report unsafe products, please refer to the EU-based contact point provided with your product packaging or visit the manufacturer's website.

By following these safety instructions, you can ensure a safe and efficient reloading experience with your Dillon XL750 Progressive Reloading Machine. Always prioritize safety and stay informed about best practices in reloading. Thank you for your attention to these important guidelines.

About Us

Brownells Italia

Brownells Italia - The shop of the largest dealer of components and accessories for target shooting guns, defense and hunting

**Sede Legale e Operativa **

Brownells Italia Srl

Via Dante Alighieri 163

25068 Sarezzo Bs

P.Iva e C.F. IT02801420981

www.brownells.it