

XL750 Progressive Reloading Machine for Rifle Calibers - Dillon

XL750 Progressive Reloading Machine 22 HORNET

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

The Dillon XL750 is a high-speed progressive reloading machine designed to load common rifle and handgun cartridges, from 17 Hornet through the common belted magnum cartridges in rifle, and 32 ACP through 500 S&W in handgun. Machine height from the bench is 32" without the optional electric case feeder, 38 1/2" with the electric casefeeder installed. A die set has to be ordered separately. Other options shown, but not included: Casefeeder, Strong Mount, Bullet Tray, Powdercheck Die and Low Powder Sensor.

NO IMAGE
AVAILABLE

Attributes

- Name: [Dillon XL750 Progressive Reloading Machine 22 HORNET](#)
- Manufacturer: [DILLON](#)
- Product no.: EU2005303
- Mfr. No.: DI75003
- Cartridge: 22 Hornet
- Delivery weight: 5.5kg

Table of Contents

- [Startpage](#)
- [Dillon XL750 Progressive Reloading Machine Safety Instruction Guide](#)
- [About Us](#)

Dillon XL750 Progressive Reloading Machine

Safety Instruction Guide

Introduction

Thank you for choosing the Dillon XL750 Progressive Reloading Machine for Rifle Calibers. This guide provides essential safety instructions to ensure the safe and effective use of your reloading machine. It is important to follow these guidelines to prevent accidents and injuries while reloading ammunition. This manual complies with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always read the entire instruction manual before using the Dillon XL750.
- Keep the reloading machine out of reach of children and vulnerable individuals.
- Ensure that the workspace is clean, dry, and welllit.
- Wear appropriate personal protective equipment (PPE), including safety glasses and hearing protection.
- Do not use the machine for any purpose other than its intended use.
- Regularly inspect the machine for any signs of wear or damage before use.
- Report any unsafe conditions or accidents to the relevant authorities.

Specific Safety Precautions for Use

- **Electrical Safety:**
 - Ensure that the machine is properly grounded.
 - Do not operate the machine with wet hands or in a wet environment.
 - Use only the recommended power supply and avoid using extension cords.
- **Handling Components:**
 - Handle all components, including dies and cartridges, with care to avoid injury.
 - Always keep fingers and hands clear of moving parts during operation.
 - Never attempt to disassemble or modify the machine without proper guidance.
- **Reloading Process:**
 - Follow the manufacturer's instructions for reloading specific cartridges.
 - Do not overload the machine beyond its specified capacity.
 - Use only approved reloading components, including powders and primers.
- **Emergency Preparedness:**
 - Familiarize yourself with the location of emergency shutoff switches.
 - Keep a fire extinguisher rated for flammable materials nearby.
 - In case of an emergency, stop the machine immediately and follow emergency procedures.

Instructions for Installation and Usage

Installation

1. Choose a Suitable Location:

- Select a sturdy and stable workbench that can support the weight of the Dillon XL750.

- Ensure the area is wellventilated and free from distractions.

2. **Mount the Machine:**

- Use the provided mounting hardware to securely attach the machine to the workbench.
- Ensure that the machine is level and stable.

3. **Install the Electric Case Feeder (if applicable):**

- Follow the manufacturer's instructions for installing the electric case feeder.
- Ensure all electrical connections are secure and compliant with safety standards.

Usage

1. **Prepare for Reloading:**

- Gather all necessary components: cases, bullets, powder, and primers.
- Check that all components are in good condition and suitable for use.

2. **Set Up the Machine:**

- Install the appropriate die set (sold separately) for the cartridge you are reloading.
- Adjust the machine settings according to the manufacturer's guidelines.

3. **Reloading Process:**

- Begin the reloading process by following the stepbystep instructions provided with the machine.
- Monitor the machine closely for any unusual noises or malfunctions during operation.

4. **PostReloading:**

- Once reloading is complete, clean the machine according to the maintenance instructions.
- Store all reloaded ammunition in a safe and secure location.

Disposal Instructions

- Dispose of any unused or expired reloading components in accordance with local regulations.
- Follow proper hazardous waste disposal procedures for materials such as primers and powders.
- Ensure that all materials are disposed of safely to prevent environmental contamination.

Contact Information for Further Support

For safety inquiries or support regarding the Dillon XL750 Progressive Reloading Machine, please refer to the manufacturer's website or contact their customer service for assistance. It is important to have a reliable source for any questions or concerns regarding the safe use of your reloading machine.

By adhering to these safety instructions, you can ensure a safe and productive reloading experience with your Dillon XL750 Progressive Reloading Machine. Always prioritize safety and follow best practices while reloading ammunition.

About Us

Brownells Italia

Brownells Italia - The shop of the largest dealer of components and accessories for target shooting guns, defense and hunting

**Sede Legale e Operativa **

Brownells Italia Srl

Via Dante Alighieri 163

25068 Sarezzo Bs

P.Iva e C.F. IT02801420981

www.brownells.it