

XL750 Progressive Reloading Machine for Rifle Calibers - Dillon XL750 Progressive Reloading Machine 300 BLACKOUT / 300 WHISPER

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

The Dillon XL750 is a high-speed progressive reloading machine designed to load common rifle and handgun cartridges, from 17 Hornet through the common belted magnum cartridges in rifle, and 32 ACP through 500 S&W in handgun. Machine height from the bench is 32" without the optional electric case feeder, 38 1/2" with the electric casefeeder installed. A die set has to be ordered separately. Other options shown, but not included: Casefeeder, Strong Mount, Bullet Tray, Powdercheck Die and Low Powder Sensor.

NO IMAGE
AVAILABLE

Attributes

- Name: [Dillon XL750 Progressive Reloading Machine 300 BLACKOUT / 300 WHISPER](#)
- Manufacturer: [DILLON](#)
- Product no.: EU2005319
- Mfr. No.: DI75022
- Cartridge: 300 AAC Blackout,300 Whisper
- Delivery weight: 5.5kg

Table of Contents

- [Startpage](#)
- [Dillon XL750 Progressive Reloading Machine Safety Instructions](#)
- [About Us](#)

Dillon XL750 Progressive Reloading Machine

Safety Instructions

Introduction

Thank you for choosing the Dillon XL750 Progressive Reloading Machine for Rifle Calibers. This safety instruction guide is designed to help you use the machine safely and effectively. Please read all instructions carefully before using the product to ensure a safe reloading experience.

General Safety Guidelines

- Always follow the manufacturer's instructions and guidelines.
- Ensure the reloading machine is used in a wellventilated area to avoid inhaling any harmful dust or fumes.
- Keep the machine out of reach of children and unauthorized users.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, when operating the machine.
- Regularly inspect the machine for any signs of damage or wear. Do not use the machine if it is damaged.
- Be aware of your surroundings and ensure that the workspace is clear of any obstructions or hazards.
- Do not overload the machine beyond its specified capacity.
- Follow all local laws and regulations regarding the reloading of ammunition.

Specific Safety Precautions for Use

- Always ensure the machine is turned off and unplugged when not in use or when performing maintenance.
- Use only recommended die sets and accessories specific to the Dillon XL750 to avoid malfunctions.
- Do not attempt to modify the machine or use it in ways not intended by the manufacturer.
- Keep fingers and hands clear of moving parts during operation to prevent injury.
- Be cautious when handling reloading components, as they may be hazardous.
- Store all reloading components and finished ammunition in a safe and secure location.
- Avoid distractions while operating the machine to maintain focus and safety.

Instructions for Installation and Usage

Installation

1. **Choose a Stable Surface:** Ensure the reloading machine is placed on a sturdy, level surface to prevent tipping or movement during operation.
2. **Mounting the Machine:** If using a Strong Mount, follow the instructions provided with the mount to securely attach the machine to your workbench.
3. **Installing the Electric Case Feeder:** If you have purchased the optional electric case feeder, follow the manufacturer's instructions for installation.
4. **Setting Up the Die:** Purchase the appropriate die set separately and install it according to the instructions provided with the die.
5. **Check All Connections:** Ensure all parts are securely fastened and that there are no loose components.

Usage

1. **Preparing the Machine:** Before starting, ensure the machine is clean and free of any debris. Check that all necessary components are in place.
2. **Loading Components:** Carefully load the appropriate components into the machine as specified in the reloading instructions. Do not exceed the recommended capacity.
3. **Operating the Machine:** Follow the operating instructions carefully. Maintain a steady pace and avoid

rushing.

4. **Monitoring the Process:** Continuously monitor the reloading process for any irregularities or malfunctions. Stop immediately if something seems wrong.
5. **Finishing Up:** Once reloading is complete, clean the machine and store it properly. Ensure all components are safely stored away from children and pets.

Disposal Instructions

- Dispose of any unused or damaged reloading components according to local regulations.
- Do not dispose of any hazardous materials in regular trash. Contact local waste management authorities for proper disposal methods.
- Ensure that the reloading machine is unplugged and cleaned before disposal.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Dillon XL750 Progressive Reloading Machine, please refer to the manufacturer's official contact points.

By adhering to these safety instructions and guidelines, you can ensure a safe and enjoyable experience with your Dillon XL750 Progressive Reloading Machine. Always prioritize safety and responsible reloading practices.

About Us

Brownells Italia

Brownells Italia - The shop of the largest dealer of components and accessories for target shooting guns, defense and hunting

**Sede Legale e Operativa **

Brownells Italia Srl

Via Dante Alighieri 163

25068 Sarezzo Bs

P.Iva e C.F. IT02801420981

www.brownells.it