

XL750 Progressive Reloading Machine for Rifle Calibers - Dillon

XL750 Progressive Reloading Machine 375 REM ULTRA MAG

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

The Dillon XL750 is a high-speed progressive reloading machine designed to load common rifle and handgun cartridges, from 17 Hornet through the common belted magnum cartridges in rifle, and 32 ACP through 500 S&W in handgun. Machine height from the bench is 32" without the optional electric case feeder, 38 1/2" with the electric casefeeder installed. A die set has to be ordered separately. Other options shown, but not included: Casefeeder, Strong Mount, Bullet Tray, Powdercheck Die and Low Powder Sensor.

NO IMAGE
AVAILABLE

Attributes

- Name: [Dillon XL750 Progressive Reloading Machine 375 REM ULTRA MAG](#)
- Manufacturer: [DILLON](#)
- Product no.: EU2005333
- Mfr. No.: DI75039
- Cartridge: 375 Remington Ultra Magnum
- Delivery weight: 5.5kg

Table of Contents

- [Startpage](#)
- [Dillon XL750 Progressive Reloading Machine Safety Instruction Guide](#)
- [About Us](#)

Dillon XL750 Progressive Reloading Machine

Safety Instruction Guide

Introduction

Thank you for choosing the Dillon XL750 Progressive Reloading Machine. This guide provides essential safety instructions and guidelines to ensure the safe and proper use of your reloading machine. Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that you fully understand the operation of the Dillon XL750 before attempting to use it.
- Always wear appropriate safety gear, including safety glasses, to protect your eyes from debris.
- Keep the reloading area clean and free from distractions.
- Store all reloading components, such as powders and primers, in a safe and secure location, away from children and pets.
- Be aware of the potential hazards associated with reloading, including the handling of gunpowder and primers.
- Follow all local laws and regulations regarding the reloading of ammunition.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Do not use the Dillon XL750 if it is damaged or malfunctioning. Inspect the machine regularly for wear and tear.
- Ensure that all components are properly installed and secured before use.
- Never exceed the recommended load limits for the machine or the ammunition being reloaded.
- Use only compatible components for reloading, including the correct dies and shell plates.
- Avoid wearing loose clothing or jewelry that could become caught in the machine during operation.
- Do not leave the machine unattended while it is in use.
- Keep hands and other body parts clear of moving parts during operation.
- Ensure proper ventilation in the reloading area to avoid inhaling any dust or fumes.

Instructions for Installation and Usage

Installation

1. **Select a Suitable Location:** Choose a stable and level surface for the Dillon XL750, ensuring that it is secure and free from clutter.
2. **Assemble the Machine:** Follow the manufacturer's instructions for assembling the Dillon XL750. Ensure all parts are fitted correctly.
3. **Install Optional Accessories:** If using optional accessories, such as the electric case feeder, follow the specific installation instructions provided with those components.
4. **Check for Stability:** Once assembled, verify that the machine is stable and does not wobble.

Usage

1. **Prepare Your Workspace:** Ensure that your workspace is organized and that you have all necessary components within reach.
2. **Set Up the Machine:**
 - Adjust the machine height as needed, either 32" without the case feeder or 38.5" with it installed.
 - Install the appropriate die set, which must be ordered separately.
3. **Loading Ammunition:**
 - Follow the reloading process as outlined in the Dillon XL750 manual.

- Pay attention to the powder check die and low powder sensor to prevent overloading or underloading.
4. **Monitor the Process:** Keep an eye on the reloading process and be ready to stop the machine if any issues arise.
 5. **PostUse Maintenance:** After using the machine, clean it thoroughly and store it in a safe, dry location.

Disposal Instructions

When disposing of the Dillon XL750 or any of its components, follow these guidelines:

- Check local regulations regarding the disposal of electronic equipment and hazardous materials.
- Do not dispose of gunpowder or primers in regular waste. Contact local authorities for proper disposal methods.
- If the machine is no longer functional, consider recycling it according to local electronic waste guidelines.

Contact Information for Further Support

For safety inquiries or further assistance regarding the Dillon XL750 Progressive Reloading Machine, please consult the product documentation or reach out to the appropriate support channels as needed.

By adhering to these safety guidelines and instructions, you can ensure a safe and efficient reloading experience with your Dillon XL750 Progressive Reloading Machine. Always prioritize safety and stay informed about best practices in reloading.

About Us

Brownells Italia

Brownells Italia - The shop of the largest dealer of components and accessories for target shooting guns, defense and hunting

**Sede Legale e Operativa **

Brownells Italia Srl

Via Dante Alighieri 163

25068 Sarezzo Bs

P.Iva e C.F. IT02801420981

www.brownells.it