

XL750 Progressive Reloading Machine for Rifle Calibers - Dillon

XL750 Progressive Reloading Machine 7.62 X 54 R

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

The Dillon XL750 is a high-speed progressive reloading machine designed to load common rifle and handgun cartridges, from 17 Hornet through the common belted magnum cartridges in rifle, and 32 ACP through 500 S&W in handgun. Machine height from the bench is 32" without the optional electric case feeder, 38 1/2" with the electric casefeeder installed. A die set has to be ordered separately. Other options shown, but not included: Casefeeder, Strong Mount, Bullet Tray, Powdercheck Die and Low Powder Sensor.

NO IMAGE
AVAILABLE

Attributes

- Name: [Dillon XL750 Progressive Reloading Machine 7.62 X 54 R](#)
- Manufacturer: [DILLON](#)
- Product no.: EU2005345
- Mfr. No.: DI75066
- Cartridge: 7.62 x 54 mm Russian
- Delivery weight: 5.5kg

Table of Contents

- [Startpage](#)
- [Dillon XL750 Progressive Reloading Machine Safety Instructions](#)
- [About Us](#)

Dillon XL750 Progressive Reloading Machine

Safety Instructions

Introduction

Thank you for choosing the Dillon XL750 Progressive Reloading Machine for Rifle Calibers. This guide provides essential safety instructions and guidelines to ensure safe and effective use of the reloading machine. Please read this document carefully before operating the machine.

General Safety Guidelines

- **Product Safety:** This machine is designed for safe use when handled properly. Ensure you understand all safety features and warnings before use.
- **Enhanced Recalls:** Stay informed about any recall notices related to this product. You can check for updates on the EU's Safety Gate platform.
- **Online Shopping:** When purchasing online, ensure that the retailer complies with safety standards similar to those in physical stores.
- **Special Consumer Focus:** This product is not intended for use by children. Always keep the machine and components out of reach of minors.
- **EU Contact Point:** For safety inquiries, please consult your retailer or the manufacturer for assistance.
- **Rapid Alerts:** Be aware of the Safety Gate system for timely updates on unsafe products.

Specific Safety Precautions for Use

- **Read Instructions:** Always read the user manual and safety instructions before operating the machine.
- **Personal Protective Equipment (PPE):** Wear safety glasses and appropriate gloves when reloading to protect against debris and chemicals.
- **Work Area:** Ensure your work area is clean, welllit, and free from distractions.
- **Electrical Safety:** If using an electric case feeder, ensure that all electrical connections are secure and comply with local regulations.
- **Handling Components:** Handle all components, including primers and powders, with care. Follow manufacturer recommendations for storage and handling.
- **Supervision:** Do not leave the machine unattended while in operation. Always supervise the reloading process.
- **Emergency Procedures:** Familiarize yourself with emergency procedures in case of an accident or malfunction.

Instructions for Installation and Usage

Installation

1. **Select Location:** Choose a stable, flat surface for installation. The machine height is 32" without the electric case feeder and 38 1/2" with it installed.
2. **Secure the Machine:** If using the Strong Mount, ensure it is properly secured to the bench to prevent movement during operation.
3. **Install Die Set:** The die set must be ordered separately. Follow the instructions provided with the die set for installation.
4. **Connect Case Feeder:** If using the electric case feeder, follow the manufacturer's instructions for connecting it safely to the machine.

Usage

1. **Set Up:** Ensure all components are correctly installed and secured before starting.
2. **Check Components:** Inspect all components, including the powder check die and low powder sensor, to

ensure they are functioning correctly.

3. **Loading Process:**

- Start with the correct cartridge type: 7.62 x 54 mm Russian.
- Follow the stepbystep reloading process as outlined in the user manual.
- Monitor the operation continuously for any irregularities.

4. **PostUse:** After reloading, clean the machine according to the maintenance instructions provided in the user manual.

Disposal Instructions

- **Disposal of Components:** Dispose of any unused or expired reloading materials, including primers and powders, according to local hazardous waste regulations.
- **Machine Disposal:** If the machine is no longer in use, recycle or dispose of it in accordance with local electronic waste disposal guidelines.

Contact Information for Further Support

For any questions or concerns regarding the Dillon XL750 Progressive Reloading Machine, please consult your retailer or the manufacturer for assistance. Always ensure you have the latest information regarding safety and product updates.

By following these safety instructions, you can ensure a safe and efficient reloading experience with your Dillon XL750 Progressive Reloading Machine.

About Us

Brownells Italia

Brownells Italia - The shop of the largest dealer of components and accessories for target shooting guns, defense and hunting

**Sede Legale e Operativa **

Brownells Italia Srl

Via Dante Alighieri 163

25068 Sarezzo Bs

P.Iva e C.F. IT02801420981

www.brownells.it