

XL750 Progressive Reloading Machine for Pistol Calibers - Dillon

XL750 Progressive Reloading Machine 45 AUTO RIM

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

The Dillon XL750 is a high-speed progressive reloading machine designed to load common rifle and handgun cartridges, from 17 Hornet through the common belted magnum cartridges in rifle, and 32 ACP through 500 S&W in handgun. Machine height from the bench is 32" without the optional electric case feeder, 38 1/2" with the electric casefeeder installed. A die set has to be ordered separately. Other options shown, but not included: Casefeeder, Strong Mount, Bullet Tray, Powdercheck Die and Low Powder Sensor.

NO IMAGE
AVAILABLE

Attributes

- Name: [Dillon XL750 Progressive Reloading Machine 45 AUTO RIM](#)
- Manufacturer: [DILLON](#)
- Product no.: EU2005362
- Mfr. No.: DI75049
- Cartridge: 45 Auto Rim
- Delivery weight: 5.5kg

Table of Contents

- [Startpage](#)
- [Dillon XL750 Progressive Reloading Machine Safety Instruction Guide](#)
- [About Us](#)

Dillon XL750 Progressive Reloading Machine

Safety Instruction Guide

Introduction

Thank you for choosing the Dillon XL750 Progressive Reloading Machine for Pistol Calibers. This guide provides essential safety instructions to ensure the safe and effective use of your reloading machine. Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the reloading machine is used only by individuals who are familiar with reloading practices and safety measures.
- Always wear appropriate safety gear, including safety glasses and hearing protection, while operating the machine.
- Keep the reloading area clean and organized to prevent accidents and ensure efficient operation.
- Store all components, including powder and primers, in a cool, dry place away from direct sunlight and heat sources.
- Do not use the reloading machine for any purpose other than its intended use.
- Regularly inspect the machine for any signs of wear or damage. Do not use if any parts are worn or damaged.
- Follow all local laws and regulations regarding the reloading of ammunition.

Specific Safety Precautions for Use

- Only use the Dillon XL750 with compatible cartridges. Refer to the product specifications for details on compatible calibers.
- Ensure that the machine is securely mounted on a stable workbench to prevent tipping or movement during operation.
- Do not overload the machine with components. Follow the manufacturer's guidelines for maximum capacity.
- Keep hands and other body parts clear of moving parts while the machine is in operation.
- If you experience any malfunctions or unusual noises, stop using the machine immediately and consult the troubleshooting section of the manual.
- Always doublecheck the powder charge before seating bullets to prevent double charges or squib loads.
- Do not leave the machine unattended while in operation.

Instructions for Installation and Usage

Installation

1. Choose a Suitable Location:

- Select a stable, flat workbench that can support the weight of the machine and provide adequate space for operation.

2. Secure the Machine:

- Use the Strong Mount to securely attach the Dillon XL750 to the workbench. Ensure that it is firmly in place before proceeding.

3. Install the Electric Case Feeder (Optional):

- If using the optional electric case feeder, follow the manufacturer's instructions for installation.
- Ensure that the feeder is properly connected and functioning before starting the reloading process.

4. Set Up Dies and Accessories:

- Install the appropriate die set for your cartridge. This must be ordered separately.
- Attach any additional accessories, such as the Bullet Tray and Powdercheck Die, as needed.

Usage

1. Preparation:

- Gather all necessary components, including brass cases, primers, powder, and bullets.
- Ensure that you have a clean and organized workspace.

2. Loading Process:

- Follow the specific loading instructions for the Dillon XL750, ensuring that each step is completed correctly.
- Monitor the operation closely, checking for any issues or irregularities.

3. PostReloading:

- After reloading, check all completed cartridges for proper seating and powder levels.
- Store the reloaded ammunition in a safe and secure location.

Disposal Instructions

- Dispose of any unused or expired components, such as powder and primers, in accordance with local regulations.
- Do not dispose of ammunition or components in regular household waste.
- Contact local authorities or hazardous waste disposal facilities for guidance on safe disposal methods.

Contact Information for Further Support

For any inquiries related to safety or product issues, please contact your local Dillon representative or authorized dealer. Ensure you have the product model and serial number ready for faster assistance.

By following these safety instructions, you can ensure a safe and efficient reloading experience with your Dillon XL750 Progressive Reloading Machine. Always prioritize safety and stay informed about best practices in reloading.

About Us

Brownells Italia

Brownells Italia - The shop of the largest dealer of components and accessories for target shooting guns, defense and hunting

**Sede Legale e Operativa **

Brownells Italia Srl

Via Dante Alighieri 163

25068 Sarezzo Bs

P.Iva e C.F. IT02801420981

www.brownells.it