

XL750 Progressive Reloading Machine for Pistol Calibers - Dillon

XL750 Progressive Reloading Machine 9MM / 38 SUPER / 9X21

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

The Dillon XL750 is a high-speed progressive reloading machine designed to load common rifle and handgun cartridges, from 17 Hornet through the common belted magnum cartridges in rifle, and 32 ACP through 500 S&W in handgun. Machine height from the bench is 32" without the optional electric case feeder, 38 1/2" with the electric casefeeder installed. A die set has to be ordered separately. Other options shown, but not included: Casefeeder, Strong Mount, Bullet Tray, Powdercheck Die and Low Powder Sensor.

NO IMAGE
AVAILABLE

Attributes

- Name: [Dillon XL750 Progressive Reloading Machine 9MM / 38 SUPER / 9X21](#)
- Manufacturer: [DILLON](#)
- Product no.: EU2005371
- Mfr. No.: DI75071
- Cartridge: 9 mm Luger,9 x 21 mm,38 Super
- Delivery weight: 5.5kg

Table of Contents

- [Startpage](#)
- [Dillon XL750 Progressive Reloading Machine Safety Instructions](#)
- [About Us](#)

Dillon XL750 Progressive Reloading Machine

Safety Instructions

Introduction

Thank you for choosing the Dillon XL750 Progressive Reloading Machine. This highspeed reloading machine is designed for loading a variety of pistol calibers, ensuring efficiency and precision in your reloading process. To ensure safe and effective use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Always read the user manual before operating the machine.
- Keep the workspace clean and organized to prevent accidents.
- Ensure proper lighting in the area where the machine is used.
- Use the machine only for its intended purpose as specified in the manual.
- Store the machine in a dry and secure location when not in use.
- Regularly inspect the machine for any signs of wear or damage.
- Keep all tools and components out of reach of children and pets.
- Do not operate the machine while under the influence of drugs or alcohol.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when operating the machine.

Specific Safety Precautions for Use

- Ensure that all safety features, such as the Low Powder Sensor, are functional before use.
- Do not exceed the maximum recommended load capacity of the machine.
- Use only compatible cartridges as specified in the product description.
- Avoid wearing loose clothing or jewelry that may get caught in moving parts.
- Keep hands and other body parts clear of moving components during operation.
- If you experience any unusual noises or vibrations, stop using the machine immediately and inspect it for issues.
- Follow all safety instructions for handling and storing reloading components, such as powders and primers.

Instructions for Installation and Usage

Installation

1. **Choose a Suitable Location:** Select a sturdy, flat surface for installation. Ensure the area is wellventilated and free from clutter.
2. **Assemble the Machine:** Follow the assembly instructions provided in the user manual. Ensure all parts are securely attached.
3. **Install Optional Accessories:** If using the electric case feeder or other accessories, follow the specific installation instructions for those components.
4. **Check Stability:** Ensure that the machine is stable and does not wobble. Adjust the Strong Mount if necessary.

Usage

1. **Prepare the Workspace:** Gather all necessary tools and materials, including cartridges, powder, primers, and tools for adjustments.
2. **Set Up the Machine:** Adjust the die set according to the specifications for the caliber you are reloading. Ensure it is securely in place.
3. **Load Components:** Carefully load the powder and primers as instructed in the user manual. Ensure that

the Low Powder Sensor is functioning.

4. **Begin Reloading:** Start the reloading process, monitoring the machine for any irregularities. Follow the stepbystep instructions in the user manual for optimal results.
5. **PostUse Care:** After reloading, clean the machine according to the maintenance instructions in the user manual. Store all components safely.

Disposal Instructions

- Dispose of any unused or expired reloading components according to local regulations.
- Do not throw away hazardous materials, such as powders or primers, in regular trash. Check with local authorities for proper disposal methods.
- Ensure that the machine is unplugged and disassembled before disposal if necessary.

Contact Information for Further Support

For any questions or concerns regarding the Dillon XL750 Progressive Reloading Machine, please refer to the manufacturer's contact information provided in the user manual.

If you encounter any unsafe products or accidents, report them to the appropriate authorities. Stay informed about recall updates through the EU's Safety Gate platform.

By following these safety instructions, you can ensure a safe and enjoyable reloading experience with your Dillon XL750 Progressive Reloading Machine. Thank you for your attention to safety and compliance.

About Us

Brownells Italia

Brownells Italia - The shop of the largest dealer of components and accessories for target shooting guns, defense and hunting

**Sede Legale e Operativa **

Brownells Italia Srl

Via Dante Alighieri 163

25068 Sarezzo Bs

P.Iva e C.F. IT02801420981

www.brownells.it