

# XL750 Progressive Reloading Machine for Pistol Calibers - Dillon

## XL750 Progressive Reloading Machine 10MM AUTO

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

The Dillon XL750 is a high-speed progressive reloading machine designed to load common rifle and handgun cartridges, from 17 Hornet through the common belted magnum cartridges in rifle, and 32 ACP through 500 S&W in handgun. Machine height from the bench is 32" without the optional electric case feeder, 38 1/2" with the electric casefeeder installed. A die set has to be ordered separately. Other options shown, but not included: Casefeeder, Strong Mount, Bullet Tray, Powdercheck Die and Low Powder Sensor.

NO IMAGE  
AVAILABLE

### Attributes

- Name: [Dillon XL750 Progressive Reloading Machine 10MM AUTO](#)
- Manufacturer: [DILLON](#)
- Product no.: EU2005374
- Mfr. No.: DI75074
- Cartridge: 10 mm Auto
- Delivery weight: 5.5kg

# Table of Contents

- [Startpage](#)
- [Dillon XL750 Progressive Reloading Machine Safety Instructions](#)
- [About Us](#)

# Dillon XL750 Progressive Reloading Machine

## Safety Instructions

### Introduction

Thank you for purchasing the Dillon XL750 Progressive Reloading Machine for Pistol Calibers. This guide provides essential safety instructions to ensure the safe and effective use of your reloading machine. Please read this manual carefully before operating the machine to minimize risks and ensure compliance with the EU General Product Safety Regulation (GPSR).

### General Safety Guidelines

- Always read and understand the user manual before using the reloading machine.
- Keep the machine out of reach of children and vulnerable individuals.
- Ensure that all safety guards and devices are in place before operation.
- Use the machine only for its intended purpose as described in this manual.
- Regularly inspect the machine for any signs of damage or wear.
- Do not modify the machine in any way that could compromise safety.
- Store the machine in a dry and secure location when not in use.
- Be aware of your surroundings and ensure that no one is in the vicinity of the machine while in operation.
- Report any unsafe conditions or incidents to the appropriate authorities.

### Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when reloading.
- Ensure that the workspace is clean and free from any obstructions that could cause accidents.
- Do not overload the machine beyond its specified capacity.
- Handle all components, including primers and powder, with care to avoid spills and accidents.
- Keep flammable materials away from the reloading area.
- Do not use the machine if you are under the influence of drugs or alcohol.
- Avoid distractions while operating the machine to maintain focus and attention.
- Follow all local regulations regarding the storage and handling of reloading materials.

### Instructions for Installation and Usage

#### Installation

##### 1. Choose a Suitable Location:

- Select a sturdy workbench that can support the weight and operation of the machine.
- Ensure adequate lighting in the workspace.

##### 2. Assemble the Machine:

- Follow the assembly instructions provided in the user manual.
- Ensure all parts are securely fastened before use.

##### 3. Install Optional Equipment:

- If using the electric case feeder or other optional accessories, follow the specific installation instructions provided.

## Usage

### 1. Preparation:

- Gather all necessary components, including brass cases, primers, powder, and bullets.
- Ensure that the machine is clean and free from debris.

### 2. Loading Components:

- Carefully load the primers, powder, and bullets according to the instructions in the user manual.
- Doublecheck that all components are correctly positioned before starting the machine.

### 3. Operating the Machine:

- Start the machine following the operational guidelines in the user manual.
- Monitor the reloading process closely and be prepared to stop the machine if any issues arise.

### 4. PostOperation:

- After use, clean the machine and store it properly.
- Dispose of any unused components or waste materials according to local regulations.

## Disposal Instructions

- Dispose of all used and unused reloading components, such as primers and powder, in accordance with local hazardous waste regulations.
- Do not dispose of these materials in regular household waste.
- Ensure that the machine is disconnected from any power source before disposal.

## Contact Information for Further Support

For any inquiries regarding safety or operational issues, please refer to the contact information provided in the product documentation. It is essential to have access to support for any concerns you may have.

By following these safety instructions, you can ensure a safe and effective reloading experience with your Dillon XL750 Progressive Reloading Machine. Thank you for prioritizing safety in your reloading activities!

# About Us

## Brownells Italia

**Brownells Italia - The shop of the largest dealer of components and accessories for target shooting guns, defense and hunting**

**Sede Legale e&nbsp; Operativa&nbsp;**

Brownells Italia Srl&nbsp;

Via Dante Alighieri 163

25068&nbsp; Sarezzo Bs

P.Iva e C.F. IT02801420981

[www.brownells.it](http://www.brownells.it)